

REFERENCE

NBS TYPE IV RF POWER METER OPERATION AND MAINTENANCE

Neil T. Larsen

BSIR 77-866

Electromagnetics Division Stitute for Basic Standards National Bureau of Standards Boulder, Colorado 80302

October 1977



U.S. DEPARTMENT OF COMMERCE, Juanita M. Kreps, Secretary Sidney Harman, Under Secretary Jordan J. Baruch, Assistant Secretary for Science and Technology

NATIONAL BUREAU OF STANDARDS, Ernest Ambler, Acting Director



NBS TYPE IV POWER METER OPERATION AND MAINTENANCE

(it

CONTENTS

	Page
LIST OF FIGURES AND TABLES	iv
ABSTRACT	v
SECTION I. GENERAL INFORMATION	1
1.0 DESCRIPTION	1
SECTION II. OPERATING INFORMATION	1
2.0 INTRODUCTION	1
2.1 PRELIMINARY OPERATING INSTRUCTIONS	1
2.2 BASIC POWER MEASUREMENT	1
2.3 PRECISION POWER MEASUREMENT	4
SECTION III. MAINTENANCE AND CALIBRATION	9
3.1 INTRODUCTION	9
3.2 TEST EQUIPMENT	9
3.3 INITIAL SETUP	9
• 3.4 POWER SUPPLY PERFORMANCE (FIG. 3-1)	10
3.5 AMPLIFIER OFFSET ADJUSTMENT (FIG. 3-3)	10
3.6 CURRENT INDICATOR (FIG. 3-3)	11
3.7 CALIBRATION OF INTERNAL RESISTORS (FIG. 3-3 & 3-4)	11
3.8 GAIN AND NOISE TESTS	12
3.9 TEST OF INTERFACE LOGIC (FIG. 3-2)	13
3.10 NONSTANDARD COMPONENTS	14
APPENDIX	28



Page

Figure	2.1.	Control identification	2
Figure	2.2.	Basic measurement system	3
Figure	2-3.	Precision measurement system using reference voltage generator (RVG)	5
Figure	2-4.	Typical voltage measurement sequence providing first-order compensation for temperature drifts	7
Figure	3-la.	Power supply drawing, serial number 122 and below	15
Figure	3-1b.	Power supply drawing, serial numbers 123 and above	16
Figure	3-2.	Interface and mount operating resistance logic	17
Figure	3-3.	Analog cicuitry for the self-balancing current loop	18
Figure	3-4.	Simplified diagram of analog circuits during calibration procedure	19
Figure	A-1.	Parts placement diagram, large board	20
		•	

TABLE A-1.	MANUFACTURER'S CODES	21
TABLE A-2.	PARTS LIST	24
TABLE A-3.	CONNECTOR PIN ASSIGNMENTS	27
TABLE 2-1.	VOLTMETER-CAUSED ERRORS	8

1,4



NBS TYPE IV POWER METER OPERATION AND MAINTENANCE

Neil T. Larsen

Operating, maintenance, and calibration procedures are provided for the NBS Type IV Power Meter. This is a recently developed instrument for rf power measurement by means of dc substitution in a bolometer (thermistor type only). Complete parts lists, schematic diagrams, and parts placement drawings are provided. Mechanical drawings are not included, but are available from: National Technical Information Service, U. S. Department of Commerce, 425 Thirteenth Street, N. W., Washington, D. C., 20004.

Key Words: Bolometer; dc substitution; microwave; power meter.

IMPORTANT NOTICE

The specific components selected for the prototype instruments were chosen on the basis of suitability, availability, and cost. They do not necessarily represent the only possible choices, or even the best choices. The National Bureau of Standards states only that they were used in the instruments described here. Substitution of nominally equivalent components meeting the same specifications should normally cause no difficulty; however, NBS has not tested all such possible choices.

v

NOTE: References to serial numbers apply only to units built by NBS.

SECTION I GENERAL INFORMATION

1.0 DESCRIPTION

The NBS Type IV RF Power Meter is designed to measure high-frequency or microwave power in conjunction with an external thermistor mount. The mount should be designed to operate at a dc resistance of either 100 or 200 ohms. A complete power measurement system will also include an accurate dc voltmeter and some means of offsetting the voltmeter so that small voltage changes may be measured more accurately. This offsetting voltage source, or reference voltage generator (RVG), is particularly important when measuring power levels below a few milliwatts.

The Type IV, unlike its predecessors, is not a self-balancing Wheatstone bridge. Instead, it passes a current through the bolometer mount while sensing the voltage across it in such a way that the resistance of the bolometer is defined at the dc terminals of the bolometer, even at the ends of long leads. This eliminates the lead errors associated with a bridge. In addition, because of this new configuration, it is now possible to change the mount operating resistance with solid state switches. Therefore, the Type IV is well suited to applications requiring high accuracy and where control by a computer is used.

SECTION II OPERATING INFORMATION

2.0 INTRODUCTION

The NBS Type IV Power Meter is a standards laboratory quality instrument used to measure accurately high-frequency or microwave power in terms of substituted dc power. The instrument is not direct reading; the power must be calculated, generally using data obtained from an external precision voltmeter. The Type IV is intended to be used with non-temperaturecompensated mounts. Two units can be used for compensated mounts (one for measurement and one for compensation). In most automated applications, the speed of measurement is such that compensation is not required. The frequency and power range is, of course, dictated by the thermistor mount used. The Type IV can supply up to 30 mA of bias current to the bolometer. This corresponds to 90 mW in 100 ohms, or 180 mW in 200 ohms.

2.1 PRELIMINARY OPERATING INSTRUCTIONS

See Figure 2.1 for the location and function of the front and rear panel controls. Before connecting the Type IV to the ac power line, check the line voltage selector for the proper setting and the fuse for the proper value. Remove the line cord, slide the window to the left and eject the fuse. The line voltage is selected by proper orientation of the small printed circuit card, which may be pulled after removing the fuse. Line voltages of nominally 100, 120, 220, and 240 may be selected. (Note: In units with serial numbers 122 and below, and using power transformer part number 13575, the 100-volt option is not available). Line voltage tolerance is plus or minus 10%. For 100-120 volt operation, a 1/8 A fast-acting fuse, 6.35 mm by 31.75 mm (0.25 by 1.25 inches) is used. For 220-240 volt operation, a 1/16 A fuse isquired.

2.2 BASIC POWER MEASUREMENT

- 1. With the instrument turned off, attach the thermistor mount to either the front panel binding posts or the rear connector. (See Appendix I for connector pin designations). If it is desired to use a 4-terminal connection to the mount to eliminate lead resistance errors, open the two links. The current-carrying conductors are connected to the red (positive) and black (negative) BOLOM binding posts. The sense leads are connected to the corresponding blue SENSE binding posts. Leads should be shielded to prevent noise pickup. Connect the shield to the black binding post and leave the other end open. See Figure 2.2.
- Attach the positive and negative input leads of the external voltmeter to the red and black binding posts marked DVM. Note that it is necessary that the voltmeter

Figure 2-1. Control identification

- 1. Bolometer current indicator, 0-30 mA.
- 2. ERROR indicator. Lights red on any fault condition preventing loop balanc
- 3. Mount operating resistance indicators (green).
- 4. Mount operating resistance switch: 100 ohms, REMOTE, 200 ohms.
- 5. Line power switch (push-push).
- 6. DVM terminals, for external voltmeter.
- 7. Positive bolometer voltage sense lead.
- 8. Positive bolometer current lead.
- 9. Negative bolometer current lead.
- 10. Negative bolometer voltage sense lead.

Front panel links connecting respective sense and current leads are not shown.

be isolated from ground, and note also that while the source resistance presented to the voltmeter by the Type IV is very low, any current drawn by the voltmeter flows through the sense lead (if used) connected to the low side of the thermistor mount. This current produces a voltage drop in the lead which causes an error. Since most digital voltmeters have very high input impedances, this is not a problem; however, it should be kept in mind that the two black terminals on the front of the instrument are not common to each other, but are connected through either the link or the sense and current leads of the cable to the mount.

- 3. Set the slide switch S101 to the 100 to 200 ohm position, as appropriate for the mount. On the rear, set the toggle switch S202 to the FLOAT position.
- 4. Turn the line power on by pressing the LINE switch S201. The correct green lamp should light, indicating the mount operating resistance. The panel meter should indicate the thermistor current. The external voltmeter should show a reading equal to the product of the thermistor current and the mount operating resistance. The ERROR lamp should be dark. If incorrect, open, or shorted connections have been made, or if the mount is open (i.e., burned out), the ERROR indicator will light. It will also light under conditions of rf power overload, or any other condition which results in the balancing servo of the instrument being unable to achieve a balance between the mount resistance and the internal resistance standard.
- 5. To measure rf power, record the voltmeter reading, apply the rf power, and read again. If temperature compensation is desired, a third reading may be taken with the power off again, and the first and third readings averaged. This assumes, for example, a linear drift in voltage with time, and an equal length of time between measurements. Then, the power, P, is given by

$$P = (V_1^2 - V_2^2)/R_0 , \qquad (1)$$

where V_1 is the output voltage in the absence of rf power (or the averaged readings mentioned above), V_2 is the voltage in the presence of rf power, and R_0 is the mount operating resistance. Thus, the so-called "bolometric power" is simply the change in the dc power in the mount. The appropriate calibration factor for the mount must be applied to this number to obtain the true rf power.

2.3 PRECISION POWER MEASUREMENT

It is apparent from equation (1) above, that as the rf power becomes small, V₂ approaches V₁. This has serious consequences for measurement accuracy. The magnification of the voltmeter uncertainties when it is used to measure two voltages which differ only slightly can be seen from Table 2-1, below. For this computation, a typical 200-ohm mount with a nominal bias current of 12.75 mA was assumed. The voltmeter specifications included: ranges of 0.1, 1, and 10 volts, with uncertainties of 0.01% of reading on all ranges, plus 0.005% of full scale on the 0.1 V range, and 0.002% of full scale on the 1 and 10 V ranges. At 1 mW, for example, the error due to the voltmeter is only 0.04% when an RVG is used; however, it is 2.3% without one.

When connected as shown in Figure 2-3, the power equation is modified to

$$P = (2V_1 - V_3)V_3/R_0, \qquad (2)$$

where $V_3 = V_1 \le V_2$. The differencing between V_1 and V_2 is now done electrically, rather than in the computation, so that the voltmeter is operating at a much larger fraction of fullscale. This minimizes the uncertainty contribution of the percent-of-fullscale specification. In effect, the RVG is used to store V_1 . The procedure is similar to that in Section 2.2.

Precision measurement system using a reference voltage generator (RVG). Figure 2-3.

- Attach the bolometer mount as described in Section 2.2. Connect the negative side of a stable voltage source (RVG) to the black DVM terminal, as shown in Figure 2-3. Arrange switching to allow the voltmeter to be connected either across the DVM terminals, or between the positive side of the RVG and the red DVM terminal.
- 2. Adjust the RVG so that its output is approximately equal to the output of the Type IV when no rf power is present. The object is to make any residual offset small compared to the lowest range on the voltmeter to be used, e.g., 10 mV on a 100 mV range. The residual offset will not cause an error, being removed in the calculation of the power from the voltmeter readings. Although it is not necessary to know exactly what the RVG output is, it is very important that the output remain stable during the time required for a measurement. Drifts should be held to less than 10 ppm.
- 3. To measure rf power with the highest accuracy and minimum sensitivity to temperature effects, the following steps are performed, usually under the control of a calculator or small computer. (Figure 2-4 summarizes these steps.)
 - 3a. Read and record the Type IV output with no rf power (V_1^{\prime}) .
 - 3b. Read and record the voltage difference between the Type IV output and the output of the RVG, still with no rf power (V_4) .
 - 3c. Turn on the rf power. Again read the voltage difference between the Type IV output and the output of the RVG (V_A) .
 - 3d. With the rf power still off, repeat step 3b to obtain V_d' .
 - 3e. Turn off the rf power and repeat step 3a to get V_1'' .
- 4. Compute the bolometric power using equation (2), as follows:
 - 4a. For V_1 , use the average value of V'_1 and V''_1 . This provides first-order compensation for temperature-induced drifts.
 - 4b. For V_3 , use $V_d (V_d^{\dagger} + V_d^{"})/2$. The term $(V_d^{\dagger} + V_c^{"})/2$ is the average value of the difference voltage with no rf and also gives first-order temperature compensation. Subtracting this average from V_d gives the true change in the output of the power meter, compensated for linear temperature changes and corrected for any initial offset due to inexact setting of the RVG. Eq. (2) now becomes

$$P = [(V' + V'') - V_d + (V_d' + V_d')/2] \cdot [V_d - (V_d' + V_d')/2]/R_o.$$
 (3)

This sequence may be modified in the software to accomodate specific situations. For example, if the bolometer mount is in a closely controlled environment, compensation may be unnecessary, and the measurement process can be speeded by eliminating unnecessary voltage readings. If the RVG is a very accurate digital-to-analog convertor (DAC), then it may be possible to rely in its calibration accuracy. In general, however, the voltmeter will be considerably more accurate than the DAC, and it is better to actually measure V_1 and V_3 than to trust the DAC. Another possible compromise is to take several readings with rf power on for every reading without it, especially, if the temperature is drifting only slowly.

Poltage via the second second

Time

,' [

RVG

Туре IV

Output

Figure 2-4. Typical voltage measurement sequence providing first-order compensation for temperature drifts. Symbols shown in the figure as the same as used in equation (3). In automatic systems, software techniques can often substitute for hardware, for temperature compensation, for example. Taking these five voltage readings with a data logger or minicomputer greatly reduces the need for precise temperature control of the bolometer mounts, while not seriously decreasing the speed.

7

. J. ..

P,mW	ERROR, %	V1 RANGE	V2 RANGE	V3 PANCE
0.100	Ø.1552	10.0000	10,0000	0 1000
0.200	0.0914	10.0000	10.0000	0.1000
0.300	0.0702	10.0000	10.0000	0.1000
0.400	0.0595	10.0000	10.0000	0.1000
0.500	0.0532	10.0000	10.0000	0.1000
0.600	0.0489	10.0000	10.0000	0.1000
0.700	0.0459	10.0000	10,0000	0.1000
0.800	0.0436	10.0000	10,0000	0.1000 0 1000
0.900	0.0419	10.0000	10,0000	0.1000 0.1000
1.000	0.0405	10.0000	10,0000	a 1000

Table 2-la. Errors due to voltmeter when RVG is used, 0.1-1 mW.

P, mw	ERROR, &	V1 RANGE	V2 RANGE
0.100	23.1772	10.0000	10.0000
0.200	11.5746	10.0000	10.0000
0.300	7.7071	10.0000	10.0000
0.400	5.7734	10.0000	10.0000
0.500	4.6131	10.0000	10,0000
0.600	3.8396	10.0000	10.0000
0.700	3.2871	10,0000	10.0000
0.800	2.8727	10,0000	10.0000
0.900	2.5504	10,0000	10 0000
1.000	2.2926	10.0000	10.0000

Table	2-1b.	Errors	due	to	voltmeter	when	no	RVG	is	used	0	1_1	mLī	
				~ ~	* OT CWCECT	witen	10	NVG.	15	usea.	· · · ·		mw	

P,mW	ERROR, 8	V1 RANGE	V2 RANGE	V3 PANCE
1.000	0.0405	10.0000	10,0000	0 1000
2.000	0.0341	10.0000	10.0000	0.1000
3.000	0.0442	10.0000	10.0000	1.0000
4.000	0.0400	10.0000	10.0000	1.0000
5.000	0.0376	10.0000	10.0000	1.0000
6.000	0.0359	10.0000	10.0000	1.0000
7.000	0.0348	10.0000	10.0000	1.0000
8.000	0.0339	10.0000	10.0000	1.0000
9.000	0.0333	10.0000	10.0000	1.0000
T0°000	0.0328	10.0000	10.0000	1.0000

Table 2-1c. Errors due to voltmeter when RVG is used, 1-10 mW.

P, mW 1.000 2.000 3.000 4.000 5.000 6.000 7.000 8.000	ERROR,% 2.2926 1.1323 0.7455 0.5520 0.4359 0.3585 0.3032 0.2617	V1 RANGE 10.0000 10.0000 10.0000 10.0000 10.0000 10.0000 10.0000 10.0000	V2 RANGE 10.000 10.000 10.000 10.000 10.000 10.000 10.000 10.000 10.000
7.000	0.3032	10.0000	10.0000
8.000	0.2617	10.0000	10.0000
9.000	0.2294	10.0000	10.0000
10.000	0.2035	10.0000	10.0000

Table 2-1d. Errors due to voltmeter when no RVC is used, 1-10 mW.

SECTION III MAINTENANCE AND CALIBRATION

3.1 INTRODUCTION

This section provides calibration and performance testing information. The adjustment procedure below assures that the unit will meet specifications. Failure of a unit is indicated by inadequate response to one or more of the adjustments, and further troubleshooting is required. This section also includes information on replacement of special components. All details refer to NBS-built units.

When it becomes necessary to remove a component from the two-sided printed circuit board, do so with great care. A solder removing tool must be used to remove solder from around the component leads. This will minimize the danger of lifting the circuit pattern from the board, a condition not easily repaired. Generally, for two-lead components, it is safer to remove the defective part by cutting the leads as close as possible to the body of the part. The replacement is then soldered to the leads of the old component.

3.2 TEST EQUIPMENT

The following test equipment is required:

- 1. DC null detector (microvoltmeter)
 Range: ± 10 microvolts fullscale to ± 30 V fullscale
 Input impedance: 100 kohms or greater, resistive
 Accuracy: ± 2% of fullscale
- 2. General purpose oscilloscope
- 3. DC milliammeter Range: 30 mA Accuracy: ± 2%
- 4. Standard resistor, 4-terminal, 100 ohms ± 0.01% or better. The accuracy of the power meter depends directly upon the accuracy of this resistor.
- 5. Thermistor mounts for 100 ohm and 200 ohm operation.
- 6. Pulse generator Required output is 1 ms pulse, negative-going from + 5 V to ground. Output impedance: 100 ohms or less
- 7. Adjustable resistance decade or 10-turn potentiometer, capable of adjustment over range of 0 to 100 ohms with 0.1% resolution. Accuracy is immaterial.
- 8. Diode, silicon, 1N4153 or equivalent.
- 9. AC voltmeters for line-voltage tests, 105-130 V.
- 10. Adjustable autotransformer for line voltage test, 117;105-130 V.
- 11. Power supply, + 5V, 25 mA minimum.
- 3.3 INITIAL SETUP
 - 1. With the instrument turned off, remove the left side by removing 2 screws each from the front and rear panels.
 - 2. Connect the links, if necessary, and connect the 1N4153 diode between the BOLOM terminals, with the anode to the red terminal. Set the 100-REM-200 switch to 100.
 - 3. Connect the instrument to the autotransformer, and set it for 105 volts.

- 4. Apply power, allow at least five minutes for warmup stabilization.
- 5. Set the GND-FLOAT switch on the rear panel to FLOAT. It should remain in that position throughout all adjustments. NOTE: The red ERROR lamp on the front panel should remain dark throughout the entire adjustment and calibration procedure, except for momentary indications when changing the setting of the 100-REM-200 switch. It is impossible to perform the adjustments if the lamp is lit, and the cause must be found and corrected.
- 6. Check the jumpers for proper placement: brown to Ell, red to E2, green to E15, blue to E6, and gray to E8. The ribbon cable connector should be seated securely in J101.
- 3.4 POWER SUPPLY PERFORMANCE (FIG. 3-1)
 - 1. There are two dual isolated supplies, each providing plus and minus 15 V. They are designated supply "A" and supply "B". The common of the A supply is connected to the black BOLOM terminal. Measure the A+ output at E7 (gray jumper) while changing the line voltage from 105 to 130 volts. It should remain in the range 14.4 to 15.6 V.
 - 2. Repeat the measurement for the A- supply; this is accessible at the case of AR101. The voltage should remain in the range 14.4 to 15.6 V.
 - 3. Repeat the measurement for the B+ supply. The B supply common is connected to E5. The B+ is accessible at the collector tab of power transistor Q115. The range of voltage is 14.4 to 15.6 volts.
 - 4. Repeat the measurement for the B- supply, which is accessible at the case of AR102. The voltage should remain in the range 14.4 to 15.6 V.

Any out-of-tolerance indications from the above tests indicate failure of one or more of the voltage regulators, filter capacitors, rectifiers, or transformer. Also, check for incorrect insertion of the line voltage selector card.

3.5 AMPLIFIER OFFSET ADJUSTMENT (FIG. 3-3)

The two operational amplifiers, AR101 and AR102, are provided with null balancing potentiometers. In making these adjustments, it is important that the amplifiers be in thermal equilibrium; heat from fingers, etc., must be allowed to dissipate before attempting a balance. In addition, the null detector used should be very well isolated from ground, preferably battery operated. The leads used with it should not exhibit large thermal emfs when handled. Proper operation of the instrument depends upon the cancellation of the emfs arising from dissimilar metals in the circuit, such as solder, copper, socket contact alloys, integrated circuit lead alloys, and so forth. This cancellation occurs only if there are no large temperature gradients across the circuit board; therefore, it is advisable to protect the unit from drafts and strong light sources with a loose cover after attaching the test leads. When a stable indication is obtained on the null detector, the adjustments may be made.

- Connect the null detector between Ell and E2. It is essential that the measurement not be made between Ell and El, because El carries current, and an error will be introduced. Adjust Rl28 for a null. A stable indication of less than ± 10 microvolts should be obtained.
- 2. Repeat for AR102 by connecting the null detector between E6 and E15 and adjusting R140.

Failure to obtain a proper null may be due to defective AR101 or AR102, or to any condition which prevents the servo from balancing, as indicated by the ERROR lamp.

3.6 CURRENT INDICATOR (FIG. 3-3)

The front panel milliammeter serves only to indicate the approximate bolometer current; it is not intended to be used for measurement. It is adjusted as follows:

- 1. Turn off the power.
- Remove one end of the diode across the BOLOM terminals and insert in series both the 0 to 100 ohm adjustable resistor and the dc milliammeter against which the adjustment is to be made. Set the 100-REM-200 switch to 100. Turn the power on.
- 3. If the ERROR lamp is lit, reduce the value of the series resistor. It should be possible to obtain an indication of 30 mA on the external meter by adjustment of the resistor. Increasing the resistance <u>increases</u> the current, because in order to maintain the series combination of diode, resistor, and external meter constant at 100 ohms, the servo must decrease the apparent resistance of the diode by increasing the current through it. Use of the diode eliminates the danger of damage to a valuable thermistor mount during this procedure.
- 4. After obtaining a current of 30 mA on the external meter, adjust R143 to bring the internal meter to full scale indication. Turn off power.
- 3.7 CALIBRATION OF INTERNAL RESISTORS (FIG. 3-3 & 3-4)

The absolute accuracy of the instrument depends upon the accuracy of the resistance against which the thermistor is compared by the servo. This resistance is composed of two adjustable resistances, connected in such a way that separate potential and current leads are available at both ends and at the junction of the two resistances. This makes it possible to define the of them (very accurately), without concern for the resistance of the circuit board pattern. The adjustment procedure is based upon the comparison technique shown in the Appendix, Figure 2. Section 3.5 must be completed before the following steps are undertaken:

- 1. Turn the power off. Remove AR101. Transfer the gray jumper from E8 to E9. Set the 100-REM-200 switch to 100.
- Open the links. Attach the 100 ohm standard resistor to the front panel terminals. The current terminals must be connected to the BOLOM binding posts of the instrument, and the potential terminals must be connected to the respective blue SENSE binding posts.
- 3. Turn the power on and allow at least 5 minutes for stabilization.
- 4. Attach the null detector between Ell and E2.

At this point, in accordance with the discussion in Appendix I, current is flowing through Q109 into E3, the junction of the two resistors. This current is now fixed, limited by R144A to about 16 mA. The null detector is reading what would be the input signal to AR101. If the internal resistor comprised of R133-R136 is not identical to the external standard, the difference in the voltage drops across the two will appear on the null detector. The sensitivity of the measurement is about 1.6 parts per million per microvolt. Since no current flows through R129-R132, the detector is connected to E2 for convenience.

- 5. Adjust R135 for a null indication on the null detector. A null of less than 10 microvolts should be obtained.
- 6. Turn the power off. Transfer the blue jumper from E6 to E4. Set the 100-REM-200 switch to 200. Turn the power on.

rent is now flowing through all of R129-R136, but AR102 is now sensing the potential at instead of E6. Therefore, R133-R136 are now outside of the loop, as far as the calibration is concerned.

- 7. Adjust R131 for a null of less than 10 microvolts.
- 8. Turn the power off. Replace AR101. Return blue jumper to E6. Return gray jumper to E8. Remove external standard.

Inability to make the above adjustments indicates failure of AR102, misadjustment of amplifier offset, failure of Q109 or Q112, or out-of-tolerance resistors in the network R129-R136. The adjustment range of each half of the resistor network comprising R129-R136 is \pm 0.05% around the nominal 100 ohm value. The nominal tolerance on the principal resistors, R130 and R134, is \pm 0.01%, so that it is unlikely that they will ever drift so far that adjustment is impossible. Worst-case accumulation of limit tolerance resistors will still allow proper adjustment. The precision of the adjustment, limited by the setability of the trimmers, is about $\frac{1}{4}$ ppm. Because of the 4-terminal connection to the external standard, lead resistances of as much as 1 ohm produce no detectable error.

If trouble is suspected, certain checks may isolate the cause. When the instrument is operating with a thermistor or diode, measure the voltage between E2 and E4 in the 100 ohm condition with a null detector. It should be essentially zero, less than 10 microvolts. A higher value indicates failure of Ql12 to turn off. A similar test can be applied to Ql09, by interchange. These transistors are MOS field effect devices with no gate protection diodes, so they may be easily damaged by static discharge. Do not allow them to contact polyethylene or polystyrene sheet or foam. Transistors Ql14 and Ql13 connect the red DVM terminal to the appropriate point, depending upon the setting of the 100-REM-200 switch. If either has excessive leakage in the off state, errors will result.

3.8 GAIN AND NOISE TESTS

The error analysis of the servo is based on a model which assumes that the amplifier differential input voltages never exceed a certain value under any condition of operation, including temperature effects and finite amplifier gain. The resulting equation is given in Appendix I equation (1). In order to ensure that the instrument is actually performing to specifications, it is necessary to measure the amplifier gains.

- 1. Set up the instrument as described in Section 2.2, preferably with a 100 ohm thermistor mount.
- 2. Connect the null detector between Ell and E2. If offset adjustment, Section 3.5 has been carried out properly, this reading should be less than 10 microvolts. Record this reading.
- 3. Record the reading of the external voltmeter.
- 4. Apply rf power to the point where the external voltmeter reading has been reduced to about 0.2 volts. Record the readings of both the null detector and the volt-meter.
- 5. Connect the null detector between E6 and E15. Repeat steps 1-4 above.

The gain of each amplifier is found by dividing the change in the external voltmeter reading by the change in the null detector reading when rf power is applied. The amplifiers used in the Type IV have a minimum gain specification of 120,000. The value will typically be larger than this. An amplifier showing a gain of less than this should be replaced and Section 3.5 should be repeated for that amplifier.

At low power levels, noise ultimately limits the usefulness of the instrument. The servo noise may be observed by connecting an oscilloscope to the DVM terminals with a diode across the BOLOM terminals, anode to the red terminal. The trace should show no "flicker" or "popcorn" noise--only a steady display of about 1 mV peak-to-peak amplitude. There should be no components present which are synchronous with the line frequency. A true-rms wideband voltmeter connected across the DVM terminals should indicate not more than 100 microvolts in a band from 10 Hz to 10 MHz.

If noise measurements are made with a thermistor, the noise due to a defective component is likely to be obscured by the excess noise generated by the thermistor bead itself. On the other hand, the diode is not a good dynamic simulation of the thermistor, because it has a virtually zero response time. Therefore, it is also informative to examine the noise with a typical mount. When this is done, line-synchronous noise will usually be seen. This is due to magnetic field leakage from the power transformer coupling with the printed circuit board pattern. Because the bandwidth of the servo is now limited by the thermistor, it cannot maintain balance for these disturbances (mostly 120 Hz and higher line harmonics). However, measurement accuracy will not be affected with most voltmeters because of the very high linefrequency rejection inherent in their design. Typical amplitudes are on the order of 3 mV peak-to-peak. The noise will now also show flicker characteristics. There is considerable variation in excess noise from one thermistor to the next.

3.9 TEST OF INTERFACE LOGIC (FIG. 3-2)

The Type IV power Meter is provided with circuitry to allow change of mount operating resistance by an external controller, and to give indication of certain kinds of malfunction to the controller. The interface is simple; most of the timing and "handshaking" circuitry must be provided by the system controller. Since it must be possible to FLOAT the unit, optoisolators are used for all digital signals in and out.

- 1. Turn the power off. It is necessary to provide 1 kohm pullup resistors for P101, pins 7, 9, and 10, in order to give an observable signal. Connect three resistors between these pins and P101-2. Connect the + 5 V supply to P101-2 also. Connect the negative side of the supply to P101-5.
- 2. Connect a diode to the BOLOM terminals, anode to red terminal. Turn the power on. Set 100-REM-200 to REM.

4. Apply the negative pulse to P101-3. The 100 indicator should light and stay lit after the pulse is removed.

If the thermistor mount is used in place of a diode, the ERROR lamp will flash momentarily during the transition from the 100 ohm state to the 200 ohm state, or vice versa. This is due to the time lag occasioned by the thermal capacity of the thermistor bead. When going from 200 ohms to 100 ohms, the lag is short because of the ability of the instrument to supply additional current rapidly; the temperature rise is also rapid. On the other hand, when cooling from 100 ohms to 200 ohms, the cooling rate is dependent solely on the mount characteristics and is determined mostly by the conduction of heat from the bead along its leads. Therefore, the ERROR light will stay on for a large part of a second. This is normal.

- 5. Monitor P101-9 with the oscilloscope while applying pulses to first P101-1 and then P101-2. A negative-going + 5 V to 0 V pulse should appear at P101-9 following every positive-going transition of the test pulse. The presence of this pulse confirms that the instrument has received the test pulse.
- Apply the test pulse to P101-1 and P101-2 simultaneously. No response pulse should be seen at P101-9. This ensures that ambiguous commands do not produce an acknowledging pulse at P101-9.
- 7. Monitor P101-10. When the test pulse is applied to P101-1, no pulse should appear at P101-10. When the test pulse is applied to P101-2, a negative-going + 5 V to 0 V pulse should appear at P101-10. This pulse provides information on the state to which the instrument has been set: it appears only when set to 100 ohms. If present, it is coincident with the pulse appearing at P101-9.

Monitor P101-7. This pin goes low whenever an out-of-balance condition occurs in the servo. This should occur after every transition from 100 to 200 ohms, or vice versa, but at no other time. This pulse may be difficult to observe unless a thermistor mount is used instead of a diode. Short the diode or thermistor mount. P101-7 should go low. This tells the system that data taken while P101-7 is low is invalid, and that a fault condition exists, such as open or shorted bolometer leads, or rf overload.

3.10 NONSTANDARD COMPONENTS

Use of unusual or nonstandard components has been kept to a minimum; however, certain components must meet critical specifications. These are:

- 1. R130 and R134, 100 ohms ± 0.01%, wirewound, specified at 23^oC and negligible power. Drift: ± 50 ppm/yr Temperature coefficient: ± 5 ppm/^oC Temperature rise (power coefficient): less than 25^oC rise per watt.
- 2. T201, power transformer. The primary is split for 117/234 volt operation. One primary is tapped for 100 volt operation; this partial winding must be able to carry the entire burden with a 100 volt supply line. Secondaries are split and shielded, 36 volts center tapped, 90 mA per winding to fullwave rectifier. The critical specification is for interwinding capacitance. Three-terminal capacitance between primary and either secondary, or between secondaries must be less than 0.01 picofarad with all shields grounded.
- 3. AT101-AT105 optoisolators. While these are not critical in the same sense as the two components mentioned above, it is desirable that the current transfer ratio be adequate to allow direct interfacting with TTL logic, while maintaining a collector swing meeting the usual 0.8 V low and 2.4 V high logic levels. Common Darlington optoisolators may not meet the 0.8 V specification.

The specific components selected for the prototype instruments were chosen on the basis of suitability, availability, and cost and do not represent the only possible choices. The National Bureau of Standards does not represent that they are the best possible for the application, only that they were used in the instruments described here. Substitution of nominally equivalent components meeting the same specifications should normally cause no difficulty; however, the National Bureau of Standards has not tested all such possible choices. In case of question, please consult with the designer.



Power supply drawing, serial numbers 122 and below. Figure 3-la.





Power supply drawing, serial numbers 123 and above. Figure 3-1b.

1.













Simplified diagram of analog circuits during calibration procedure. The null detector replaces amplifier AR101. Figure 3-4.





Figure A-1. Parts placement diagram, larger board.

20

1."



MANUFACTURER'S CODES

3M

3M Company, Electronic Products Division 3M Center St. Paul, Minnesota 55101

AB

Allen-Bradley Company 1201 S. Second Street Milwaukee, Wisconsin 53204

ALCO

Alcoswitch Division of Alco Electronic Products, Inc. P. O. Box 1348 Lawrence, Massachusetts Ø1842

AMPH

Bunker Ramo Sales Division 2875 South 25th Street Broadview, Illinois 60153

API

LFE Corporation, Process Control Division 1601 Trapelo Road Waltham, Massachusetts 02154

AZTE

Aztec Electronics, Incorporated 1240 Blue Gum Street Anaheim, California 92806

BELD

Belden Corporation, Electronic Division P. O. Box 1331 Richmond, Indiana 47374

BOUR

Bourns, Incorporated, Trimpot Division 1200 Columbia Avenue Riverside, California 92507

CA

Circuit Assembly Corporation 3169 Red Hill Avenue Costa Mesa, California 92626

CAMB

Cambridge Thermionic Corporation 445 Concord Avenue Cambridge, Massachusetts 02138

CORC

Corcom, Incorporated 2635 North Kildare Avenue Chicago, Illinois 60639

CORN

Corning Glass Works, Electronic Products Division Houghton Park, Bldg. A-2 Corning, New York 14830



MANUFACTURER'S CODES, CONTINUED

DALE

Dale Electronics, Incorporated Box 609 Columbus, Nebraska 68601

DEST

Destek Industries P. O. Box 24163 Los Angeles, California 90024

ELCO

ELCO Maryland Road & Computer Avenue Willow Grove, Pennsylvania 19090

ERIE

Erie Technological Products 644 West 12th Street Erie, Pennsylvania 16512

ESI

Electro Scientific Industries 13900 N. W. Science Park Drive Portland, Oregon 97229

GE

General Electric Co., Semiconductor Products Department Electronics Park, Box 1122 Syracuse, New York 13201

GENE

General Instrument Corp., Semiconductor Products Division 600 West John Street Hicksville, New York 11802

HHSM

Herman H. Smith, Incorporated 812 Snediker Avenue Brooklyn, New York 11207

H₽

Hewlett-Packard, Optoelectronic Division 640 Page Mill Road Palo Alto, California 94304

JBT

J-B-T Instruments, Incorporated Box 1904 New Haven, Connecticut 06509

KEME

Union Carbide Corporation, Components Department Box 5928 Greenville, South Carolina 29606

KODA

Eastman Kodak Company 343 State Street Rochestor, New York 14650



MANUFACTURER'S CODES, CONTINUED

LITR

Litronix, Incorporated 19000 Homestead Road Cupertino, California 95014

MOTO

Motorola Semiconductor Products 2002 West 10th Place Tempe, Arizona 85281

PMI

Precision Monolithics, Incorporated 1500 Space Drive Santa Clara, California 95050

RCA

RCA Solid State Division Route 202 Somerville, New Jersey Ø8876

SCHA

IEE/Schadow, Incorporated 8081 Wallace Road Eden Prairie, Minnesota 55343

SIGN

Signetics Corporation 811 East Arques Avenue Sunnyvale, California 94086

SPRA

Sprague Electric Company 481 Marshall Street North Adams, Massachusetts Ø1247

SUPR

Superior Electric Company 1000 Middle Street Briston, Connecticut 06010

THER

Thermalloy, Incorporated 2021 West Valley View Dallas, Texas 75234

ULTR

Ultronix, Incorporated P. O. Box 1090 Grand Junction, Colorado 81501

USEC

USECO Division, Litton Industries 13536 Saticoy Street Van Nuys, California 91409



PARTS LIST

CATEGORY	NO.	1		RE	SISTORS				
1 R101	3	CARBON,	0.25w,	5%	1000 OHMS	AB	FSN	5905-681-6462	
2 R102	11	CARBON,	0.25W,	58	33 KOHMS	AB	FSN	5905-577-9602	
3 R103		SAME AS	R102						
4 R104	6	CARBON,	Ø.25W,	5%	750 OHMS	AB	FSN	5905-807-4954	
5 R105		SAME AS	R104						
6 R106		SAME AS	R104						
7 R107		SAME AS	R102						
8 R108		SAME AS	R102						
9 R109		SAME AS	R102						
10 R110	2	CARBON,	Ø.25W,	5%	15 KOHMS	AB	FSN	5905-681-8818	
11 R111		SAME AS	R102						
12 R112		SAME AS	R1Ø2						
13 R113		SAME AS	R102						
14 R114		SAME AS	R102						
15 R115	3	CARBON,	Ø.25W,	58	100 KOHMS	AB	FSN	5905-686-3129	
16 R116		SAME AS	R104						
17 R118		SAME AS	R102						
18 R119	2	CARBON,	0.25W,	5%	330 KOHMS	AB	FSN	5905-686-3131	
19 R119	A	SAME AS	R115						
20 R120		SAME AS	R119						
21 R121		SAME AS	R104						
22 R122		SAME AS	R125						
23 R123	1	CARBON,	0.25W,	58	16 OHMS	AB	FSN	5905-835-1630	
24 R124		SAME AS	R104						
25 R125		SAME AS	R110						
26 R126		SAME AS	R102						
27 R127	2	CARBON,	0.25W,	58	1 MOHM	AB	FSN	5905-681-8817	
28 R128	2	TRIMMER	, METAL	FILM	20 KOHM	BOUR	3009	9P-1-203	
29 R129	2	METAL F	ILM, Ø.	125W, 1%	9530 OHMS	CORN			
30 R130	2	WIREWOU	ND, 0.0	18	100 OHMS	ESI	RF6	R	
31 R131	2	TRIMMER	, METAL	FILM	1 KOHM	BOUR	3009	9P-1-102	
32 R132	2	WIREWOU	ND, 1%,	Ø.15W	1 OHM	DALE	RB5!	5CE1RØØØF	
33 R133		SAME AS	R129						
34 R134		SAME AS	R130						
35 R135		SAME AS	R131						
36 R136		SAME AS	R132						
37 R137		SAME AS	R101						
38 R138	1	CARBON,	Ø.25W,	58	22 KOHMS	AB	FSN	5905-687-0002	
39 R139		SAME AS	R101						
40 R140		SAME AS	R128						
41 R141	1	CARBON,	0.25W,	58	10 OHMS	AB	FSN	5905-817-7971	
42 R142	1	CARBON,	Ø.25W,	5%	220 OHMS	AB	FSN	5905-683-2240	
43 R143	1	TRIMMER	, METAL	FILM	100 OHMS	BOUR	332	9H-100	
44 R144		SAME AS	R127						
45 R144	A 1	CARBON,	0.5W,	5%	820 OHMS	AB			
				••					
CAMECOD	V NO	2		CA	PACITORS				
CALEGOR	1 140	• 2		G.	1110110340				
1 010	1		ERAMIC	IKV	1000 PF	ERIE	80	1-000-x5FO-102K	
2 010	1 2	CAME A	S CIQI	4 07 V					
2 010	2	1 METIALI	JZED FT	LM. 100V	0.047 MF	SPRA	22	5P47391WD3	
3 C10	1	A ATTIMIN	UM. 250		220 MF	SPRA	50	3D227G035DK	
4 020	2	STOLIN	S (201		And the form to the				
5 020	2	CVWE V	S C201						
7 020	A	SPULL N	S C 201						
7 020	-9		C C GUI						
					24				

24



PARTS LIST, CONTINUED

	8 C205 9 C206 10 C207	4 SOLID TANTALUM, 35V SAME AS C205 SAME AS C205 SAME AS C205	l MF	KEME	T330A105K035AS
	12 C209 13 C210 14 C211 15 C212	4 SOLID TANTALUM, 25V SAME AS C209 SAME AS C209 SAME AS C209	4.7 MF	KEME	T330A475K025AS
	CATEGORY N	0. 3	TRANSISTORS		
	1 Q101 2 Q102 3 Q103 4 Q104 5 Q105 6 Q106 7 Q107 8 Q108	9 SILICON NPN SAME AS Q101 SAME AS Q101 SAME AS Q101 SAME AS Q101 SAME AS Q101 SAME AS Q101	2N3904	MOTO	FSN 5961-892-8706
	9 Q109 10 Q110 11 Q111 12 Q112	4 MOSFET, N-CHANNEL 2 SILICON NPN DARLINGTON SAME AS Q101 SAME AS Q109	SD210 N MPS-U45	SIGN MOTO	
)	13 Q112A 14 Q113 15 Q114 16 Q115	l SILICON PNP SAME AS Q109 SAME AS Q109 SAME AS Q110	2N3906	MOTO	FSN 5961-931-Ø372
	CATEGORY N	NO. 4	DIODES		
	1 CR101 2 CR102 3 CR103 4 CR104 5 CR105	1 ZENER, 4.7V, 10%, 0.5 7 SILICON SIGNAL SAME AS CR102 SAME AS CR102 SAME AS CR102	W 1N5230A 1N4153	MOTO GE	
	6 CR106 7 CR107 8 CR108 9 CR109	1 ZENER, 24V, 10%, 0.5W SAME AS CR102 SAME AS CR102 SAME AS CR102	1N5252A	MOTO	
	10 CR201 11 CR202	2 RECTIFIER, FW BRIDGE SAME AS CR201	WØ2M	GENE	
	12 DS101 13 DS102	2 LED, GREEN SAME AS DS101		HP	5082-4955
	14 DS103	l LED, RED		HP	5082-4655
	CATEGORY I	NO. 5INTE	GRATED CIRCUI	TS	
	1 AR101 2 AR102	2 OPERATIONAL AMPLIFIER	R OP-05CJ	PMI	
	3 AT101 4 AT102 5 AT103 6 AT104	5 OPTO-ISOLATOR SAME AS AT101 SAME AS AT101 SAME AS AT101	IL-5	LITR	
1	8 U1	SAME AS ATIVI 1 CMOS, QUAD 2-INPUT NA	AND CD4011AE	RCA	



PARTS LIST, CONTINUED

9	U2	1 CMOS, QUAD EX-OR	CD4030AE	RCA
10	VR201	2 VOLTAGE REGULATOR, 15V	MC7815C	MOTO
11	VR202	2 VOLTAGE REGULATOR, -15V	MC7915C	MOTO
12	VR2Ø3	SAME AS VR201		
13	VR204	SAME AS VR202		

CATEGORY NO. 6-----CONNECTORS-----2 8-PIN PTFE SOCKET 5 6-PIN DIP SOCKET 2 14-PIN DIP TERMINATION AMPH 631 26011 082 1 CAMB 703-3771-01-03-16 3M 3406-1000 AMPH 631 26011 042 2 3 4 4 4-PIN PTFE SOCKET 5 J101 3 14-PIN DIP SOCKET CA CA-14LS1-10SD 3M 3473-3000 6 NONE 2 MATE TO P101, P102 7 NONE SAME AS J101 8 P101 2 10 PIN MALE SCOTCHFLEX 3M 3491-1002 9 P102 SAME AS P101

1 E1-15 10 PC VERTICAL HERMAPHRO ELCO 62-5201-02-13-00-011 ELCO 00-60-8017-0313 SUPR DF21BC SUPR DF21BLC 2 El-15 5 CRIMP HERMAPHRO 3 E201 2 BINDING POST, BLACK 4 E202 2 BINDING POST, BLUE 5 E203 SAME AS E202 SUPR DF21RC 6 E204 2 BINDING POST, RED 7 E205 SAME AS E204 8 E206 SAME AS E201 9 E16-21 6 TERMINAL, FORK, STAKED USEC 2001B1

CATEGORY NO. 7-----TERMINALS-----

CATEGORY NO. 8-----SWITCHES-----ALCO MSS-1300 SCHA ZFFA200BLK/GR2UNEI5 JBT JMT 123

1 S101 1 SP3T SLIDE 2 S201 1 2PDT PUSH-PUSH 3 S202 1 SPDT TOGGLE

CATEGORY NO. 9-----METERS-----

 1 0-1 MA, 32 OHM COIL
 API
 1015-0003-0000

 1 METER SCALE MATERIAL
 KODA
 CAT. NO. 157 8285
 1 M1 2

CATEGORY NO. 10------HARDWARE-----6 SPACER, HEX BRASS6-32X0.25HHSM2320 (GOLD FLASH ADDED)1 CHASSIS AND PANELSDESTK-33-9 (NO OPTIONS)6 MACHINE SCREWS6-32X3/16NPBH BRASS6 WASHERS#6 SMALLBRASS (GOLD FLASH ADDED)2 SWING LUGS, GOLDPLATEDESI32471 STOP, 1X4.5X0.062 IN6061-T6ALUMINUM, SET W/EPOXY 1 2 3 4 BRASS (GOLD FLASH ADDED) 5 6



PARTS LIST, CONTINUED

CATEGORIES 11 AND 12 ARE EMPTY.

CATEGORY NO. 13-----MISCELLANEOUS-----

1	1 LINE CORD	В	BELD 17250
2	WIRE, PRIMARY POWER	2-#24 AWG B	BELD 8461
3 A201	1 LINE CONNECTOR/SELECTOR	С	CORC 6J4
4 T201	1 TRANSFORMER, POWER	117/36/36 A	AZTE 13575 (SER 122 & BELOW)
5 T201	1 TRANSFORMER, POWER	117/36/36 A	AZTE 13886 (SER 123 & ABOVE)
6	4 MOUNTING PAD, C201-C204	Т	THER 7717-204

TABLE A-3

CONNECTOR PIN ASSIGNMENTS

1 Pull low to set mount operating resistance to 200 ohms.

2 External +5 volt power for optoisolators. Drain is less than 5 mA.

3 Pull low to set mount operating resistance to 100 ohms.

4 Not used.

101:

5 External common.

-DVM: Bolometer negative sense lead, black front panel DVM post E206 (also E202).
Goes low on any error condition; data is invalid when pin 7 is low.

8 +DVM: Red front panel DVM post E206.

9 Goes low to acknowledge completion of setting mount operating resistance (approximately 1 millisecond pulse, +5 volts to 0 and back to +5 volts.
10 Check signal to acknowledge that specified mount operating resistance was set.

If mount was set to 100 ohms, a pulse identical to and coincident with the pulse on pin 9 appears. If the mount was set to 200 ohms, no pulse appears.

P102:

Bolometer negative sense lead, in parallel with front panel blue post E202. Not used.

Bolometer negative current lead, in parallel with front panel black post E201.
Same as pin 1, Pl02.

- 5 Bolometer positive current lead, in parallel with front panel red post E204. Not used.
- 7 Bolometer positive sense lead, in parallel with front panel blue post E203.
- 8 Not used.

9 Not used.

10 Not used.



A New Self-Balancing DC-Substitution RF Power Meter

NEIL T. LARSEN, MEMBER, IEEE

Abstract—Problems intrinsic in self-balancing Wheatstone bridges have led to the development of a new dc substitution microwave power meter. The new instrument allows four-terminal measurement of bolometer resistance and affords improved accuracy and lower noise at a lower cost than earlier instruments. Measurement errors due to imperfect behavior of the servo system are typically less than 0.01 percent.

INTRODUCTION

FOR MANY YEARS the highest accuracy in microwave power measurements in the range from 0.1 to 10 mW has been achieved with bolometers, using dc substitution techniques. The first such precision instrument was a self-balancing Wheatstone bridge described by Engen in 1957 [1]. In 1970, we described an improved instrument which also was a self-balancing Wheatstone bridge but included a power-leveling capability and a differential voltmeter [2]. We now describe a new dc substitution power meter which provides certain advantages over the earlier instruments in lower cost, greatly simplified circuitry, improved signal-to-noise ratio in the output signal, and the reduction or elimination of certain errors.

BACKGROUND

Fig. 1 shows the form of the original self-balancing Wheatstone bridge, with a bolometer in one arm. The operational amplifier senses the error voltage across the horizontal diagonal of the bridge and drives the top of the bridge to heat the bolometer to a point which closely approximates bridge balance. The voltage across the vertical diagonal is measured before and after the RF power is applied, and the unknown RF power is related to the change in the computed dc power in the bolometer through the constants of the bolometer mount.

This straightforward approach is subject to certain problems, however. First, as RF power is dissipated in the bolometer, the common-mode voltage at the amplifier input changes; therefore, an amplifier having a high common-mode rejection ratio (CMRR) is required for accurate measurement. Second, the bolometer is a two-terminal device which typically must be located at some distance from the other three arms of the self-balancing bridge, since in most systems, the terminal surface of the RF portion of the system dictates the physical location of the bolometer mount. It is not common practice, nor is it usually feasible, to separate the resistances associated with



Fig. 1. Self-balancing Wheatstone bridge.

the leads to the bolometer from the bolometer itself. This causes a first-order error in the measurement of the substituted power unless the actual lead resistances are measured separately, and corresponding corrections calculated for each different set of leads.

The third problem is more subtle. Consider equivalent noise-voltage generators in series with each of the input leads of the balancing amplifier. If there is no feedback from the output of the amplifier to the inverting input, then the noise will be amplified by the full open-loop gain of the amplifier and will appear at the top of the bridge the point from which the output signal is taken. Since it is the purpose of the servo system to maintain the bridge in balance as exactly as possible, the result is a closed-loop gain for noise that is higher than the closed-loop gain for the dc signal (at those frequencies where the attenuation of the feedback path is high and the amplifier has gain). This conflict is an intrinsic problem in all systems which use a self-balancing dc bridge.

THE BASIC CIRCUIT

Active measuring circuits of various kinds incorporating operational amplifiers and isolated power supplies are not new. In 1954 Hoge [3] proposed a manually balanced circuit for the intercomparison of two four-terminal resistors. Although his system was manually operated, his concept bears some interesting similarities to the circuit described below. Others [4], [5] have reported on resistance ratio measurement techniques involving operational amplifiers. However, the prior work has dealt exclusively with linear systems involving linear resistances. In Fig. 2, an operational amplifier and associated power supply are connected with two four-terminal resistors and an external voltage source in such a way that a current I, flows through R_1 . Under the assumption of an ideal amplifier, the current will flow as shown, and because by hypothesis no currents flow in the amplifier input leads, exactly the same current flows out of the power supply common terminal back

Manuscript received June 30, 1976.

The author is with the Electromagnetics Division, National Bureau of Standards, Boulder, CO 80302.



IEEE TRANSACTIONS ON INSTRUMENTATION AND MEASUREMENT, DECEMBER 1976



Fig. 2. A method for intercomparing two four-terminal resistors.



Fig. 3. A self-adjusting current loop.

bugh R_2 to the adjustable source. The amplifier maintains the current at such a level as to keep a zero potential difference between its input leads at all times. A voltmeter connected between the other two potential terminals of R_1 and R_2 will display a reading which is proportional to the difference in resistance between R_1 and R_2 .

Now consider replacing R_2 by a negative temperature coefficient bolometer (a thermistor). If the source is varied, the current I will vary. This will cause the bolometer resistance to change and will produce a varying indication on the voltmeter. This immediately suggests closing a second feedback loop in such a way that the source voltage is controlled by the voltmeter reading to produce a voltmeter reading of zero. This concept is shown in Fig. 3, where the voltmeter and source have been replaced by a second operational amplifier and its power supplies. If a current I flows through R_1 , by the previous argument, the current flowing through R_2 is identically the same. The amplifiers maintain a zero potential difference across their respective inputs by controlling these identical currents. Thus, since R_1 and R_2 have identical voltage drops across them for identical currents, R_2 must be equal to R_1 . This circuit therefore forces the bolometer resistance into equality with R_1 , and it does so on a four-terminal hasis. This allows the elimination of the lead-error problem intrinsic to a Wheatstone bridge. The circuit has two stable states, since the current can, in principle, flow in either direction. However, once the current flow has been esshed, the self-balancing servo is quite stable. It is a initial matter to provide for a predetermined direction of flow in an actual instrument.



Fig. 4. Error sources in the loop. Current I_1 is the desired bolometer current.

The circuit also has interesting symmetry properties. For example, in one configuration the amplifier common-mode voltages are identically zero if the lead resistances are zero. This would allow the use of chopper-stabilized three-terminal amplifiers instead of differential amplifiers. Finally, the system works equally well with positive temperature coefficient bolometers (barretters) by interchanging the bolometer and R_1 . In all, a total of eight configurations result from various combinations of amplifier configurations and bolometers.

ERROR ANALYSIS

The error sources in the system due to the limitations of the operational amplifiers and the reference resistor R_1 are shown in Fig. 4. The assumptions are that the amplifier input bias currents are small but finite, that leakage currents flowing into or out of each operational amplifier and its power supplies are negligibly small, and that the amplifier input offset voltages are small but finite. The amplifier gain is assumed to be large but finite. Equation (1) summarizes the results of the analysis.

$$P = \frac{(2V_1 - V_3)V_3}{R_0}$$

$$\cdot \left[1 - X - \frac{E_1}{2V_1 - V_3} \left(1 - \frac{R_0^2}{\gamma V_1 (V_1 - V_3)} \right) - \frac{E_2}{2V_1 - V_3} \left(1 + \frac{R_0^2}{\gamma V_1 (V_1 - V_3)} \right) + \frac{R_0 (I_3 - I_5)}{2V_1 - V_3} \left(1 - \frac{R_0^2}{\gamma V_1 (V_1 - V_3)} \right) + \frac{2}{2V_1 - V_3} \left(V_1 \alpha_1 + S_1 \beta_1 + (V_1 - V_3) \alpha_3 + \frac{(V_1 - V_3)S_3 \beta_3}{V_3} \right) \right]$$
(1)

where

 V_1 = output voltage with no RF power V_2 = output voltage with RF power $V_3 = V_1 - V_2$ γ = bolometer coefficient Ω/W





Fig. 5. Voltmeter errors with and without offsetting reference voltage generator. Total servo errors with bias currents of 6 nA and amplifier offsets of 10 μV.

 S_1, S_2, S_3 = range (full scale) of the external voltmeter when measuring V_1 , V_2 , and V_3 , respectively

 $\alpha_1, \alpha_2, \alpha_3$ = fraction of reading error in the external voltmeter when measuring V_1, V_2 , and V_3 , respectively

 β_1,β_2,β_3 = fraction of full scale error in the external voltmeter when measuring V_1 , V_2 , and V_3 , respectively.

The remaining terms in the equation are shown in Fig. 4. Error voltages E_1 and E_2 are due to the combined effect of amplifier offset and finite gain. The loop current is I_1 , and I_3 through I_6 represent the amplifier input bias currents. The nominal resistance of the reference resistor is R_0 , and it may be in error by the fractional amount X. The bolometer is represented by the element T, which has an ohms-per-watt coefficient γ .

The first error term is due to the reference resistor and is not dependent on the RF power level. The second term is due to the finite amplifier gains and offsets and is a function of the RF power level. The third term is due to the amplifier input bias currents. Note that two of the four bias currents, I_4 and I_6 , do not appear in the equation because they do not flow through either of the resistors in the configuration which was shown in Fig. 4. The servo errors in (1) are plotted in Fig. 5 for a typical coaxial dual-element thermistor mount with an ohms-per-watt coefficient of 13 000 and a bias current of 12.8 mA. The normal maximum RF power level for this type of mount is limited to 10 mW because of the dual-element substitution error; however, the curves have been continued to current cutoff to show the behavior of the errors. Only the power-dependent errors are shown here. The errors due to the external voltmeter are also shown in the upper two curves. If a stable variable voltage source (i.e., a "reference generator") is used to offset the voltmeter so that it is always used at as great a fraction of full-scale indication as possible, the middle curve results. If the reference generator is not used, then the voltmeter errors are magnified by using it to measure two voltages $(V_1 \text{ and } V_2)$ which are nearly the same, and then taking the difference of the squares.

We have described the errors due to the limitations of operational amplifiers and resistors. Unfortunately, the principal source of error in an actual power measurement is the limited accuracy of the external voltage measuring equipment. The errors due to the voltmeter alone are typically 20 times those due to the servo, with voltmeter specifications typical of high quality digital instruments.

PRACTICAL REALIZATION

The unique features of the self-balancing circuitry described above make this instrument especially attractive in applications where automatic control is desired. It is often necessary to assemble several power meters in a given system, one for each of several output ports. The use of four-terminal connections to both the reference resistor and the bolometer make it possible to bring long leads from



Fig. 6. Dual isolated power supplies.



IEEE TRANSACTIONS ON INSTRUMENTATION AND MEASUREMENT, DECEMBER 1976



Fig. 7. Interface logic.

the bolometer units to a central instrumentation console without introducing errors. In addition, it is now possible to control the operating resistance of the bolometer unit by changing the reference resistor in response to an electrical control signal. This is much more difficult to do in a Wheatstone bridge because the contact resistance of the switches cannot be entirely removed from the bridge circuit. Now, however, it is possible to use field-effect transistor switches with no degradation in the measurement accuracy.

346

A complete schematic diagram is shown in Figs. 6, 7, and 8. The bulk of the circuitry is involved with the interface between the power meter and an external controller. The self-balancing portion is shown in Fig. 8. The reference resistor is comprised of R_{129} through R_{136} . It is arranged in such a way that by switching the current terminals, the effective resistance can be changed from 100 to 200 Ω . This switching is accomplished by the field-effect transistors. In addition, by removing AR101 from its socket, these resistors can be calibrated against an external four-terminal standard attached to the bolometer terminals using essentially the technique shown in Fig. 2.

The remote control inputs are applied at the left side of Fig. 7 through optical isolators. They allow an external controller to set the mount operating resistance to either 00 or 200 Ω . The mount operating resistance is determined by S101: 100 Ω , REMOTE, and 200 Ω . When in the REMOTE position, a negative-true pulse applied to ter-

minals B or C will set the operating resistance accordingly. An elementary "hand-shake" return signal is provided at Pin D and a logic level confirming that the correct resistance was set appears at Pin E.

If the balancing servo goes out of control due to RF overload, broken or shorted lead wires, switching transients in changeover from one operating resistance to another, or a burned-out bolometer, then a front panel warning light appears, and a control signal appears between Pins F and G of the interface. This signal may be used to protect bolometer mounts against RF overload or to prevent the data acquisition portion of the system from taking invalid data.

The instrument as shown is designed to accept only negative temperature coefficient bolometers. The addition of a barretter capability requires only the incorporation of a 4PDT switch to interchange the amplifier input leads for example.

The signal output to the external voltmeter may be taken either from a terminal pair which is switched automatically as the mount operating resistance is switched, or from terminals connected directly to the reference resistor if the on-resistance of the switches cannot be tolerated. This resistance is less than 50 Ω . The Thevenin equivalent source resistance measured, for example, between terminals 2 and E- in Fig. 8, is very small (microohms) because of the large amount of feedback in the loop.





Fig. 8. Self-halancing current loop. The bolometer is connected to the terminals identified by I -, E -, E +, and I +.

PERFORMANCE

Performance of the instrument was measured in two ways. First, the magnitudes of the offset voltages and bias currents were measured under conditions of changing RF power to verify that the values used for these terms in the error analysis were realistic. Second, a system was assembled that allowed a comparison of the new instrument with an NBS Type II power meter. Mounts for the two power meters were attached to two arms of a "magic tee" or other power divider. The Type II was used to control and measure the power level from a source, while the Type IV measured the power on the other arm. The two power levels were nominally equal. The entire measurement system was under the control of a programmable calculator. Power levels were selected at random by the calculator, typically over the range of 0.1 to 15 mW, and the ratio of the bolometric powers at the two ports computed. The independence of this ratio was a measure of the precision of the two power meters and of their relative linearity. The standard deviation of a series of 1024 measurements of randomly selected levels was about 0.008 percent. The series was repeated several times for different combinations of single and dual-element mounts, with similar results. Since the two power meters were quite different internally, this is also indicative of the absolute linearity of each.

SUMMARY

We have described a new dc substitution self-balancing RF power meter which is not a form of Wheatstone bridge. Its advantages include reduced cost, lower noise, improved ease of adjustment, and adaptability to automatic control. A disadvantage is the requirement for a highly isolated power supply. The technique may also be useful with hot-wire anemometers. A patent is pending.

ACKNOWLEDGMENT

The author wishes to acknowledge the contributions of G. Reeve in early discussions, and the construction of the prototype instrument by W. Boone. This work was supported in part by the U.S. Army, U.S. Navy, U.S. Air Force, and the Energy Resources Development Administration.

References

- G. F. Engen, "A self-balancing direct-current bridge for accurate bolometric power measurement," NBS J. Res., vol. 59, no. 2, pp. 101–105, Aug. 1957.
- [2] N. T. Larsen and F. R. Clague, "The NBS type II power measurement system," Adv. Instrum, vol. 25, Pt. 3, paper no. 712-70, in Proc. 25th Annu. ISA Conf. (Philadelphia, PA), Oct. 26-29, 1970.
- [3] H. J. Hoge, "A two emf method for the comparison of resistances," *Rev. Sci. Instrum.*, vol. 25, no. 9, pp. 902-907, Sept. 1954.
- [4] L. Crovini and C. G. M. Kirby, "Resistance comparisons at nanovolt levels using an isolating current ratio generator," *Rev. Sci. Instrum.*, vol. 41, no. 4, pp. 493–497, Apr. 1970.
- [5] M. L. Roberts, "Potentiometric bridge for resistance thermometry," ISA Trans., vol. 8, no. 2, pp. 157–162, 1969.

