

A11102 970811

NBSIR 88-3743

NIST
PUBLICATIONS

INTEGRATED MANUFACTURING DATA ADMINISTRATION SYSTEM (IMDAS) OPERATIONS MANUAL

April 21, 1988

By:
Deborah A. Nickerson



QC
100
.U56
#88-3743
1988
c.2

NATIONAL INSTITUTE OF STANDARDS &
TECHNOLOGY
Research Information Center
Gaithersburg, MD 20899

NISTC
QC100
.456
no. 88-3743
1988
C.2

INTEGRATED MANUFACTURING DATA ADMINISTRATION SYSTEM
OPERATIONS MANUAL

Deborah A. Nickerson

Integrated Systems Group
Factory Automation Systems Division
National Bureau of Standards

April 21, 1988

DISCLAIMER

Certain commercial equipment, instruments, or materials are identified in this paper in order to adequately specify the experimental procedure. Such identification does not imply recommendation or endorsement by the National Bureau of Standards, nor does it imply that the materials or equipment identified are necessarily the best available for the purpose.

This publication was prepared by United States Government employees as part of their official duties and is, therefore, a work of the U.S. Government and not subject to copyright.

INTEGRATED MANUFACTURING DATA ADMINISTRATION SYSTEM
OPERATIONS MANUAL

I.	Introduction	1-2
	1. Purpose of This Document	
	2. Modes of Operation	
	3. Contacts for Errors	
	4. Conventions Used in This Document	
	4.1. Keyboard Conventions	
	4.1.1. Carriage Return	
	4.1.2. Delete	
	4.2. Sun References	
	4.3. VAX References	
	4.4. NETWORK References	
II.	Devices Needed	3
	1. Foreground Mode	
	2. Background Mode	
III.	Foreground Mode	4-6
	1. Sun Startup	
	1.1. Lockscreen Mode	
	1.2. Power off	
	2. Login	
	3. IMDAS Startup	
	4. Connecting AMRF Systems	
	5. Bringing Down the IMDAS	
	6. Logging Out	
	6.1. Logging Out Connections to the VAX	
	6.2. Logging Out of the IMDAS Sun Account	
IV.	Background Mode	7-9
	1. Login	
	2. Enter IMDAS Directory	
	3. Background Startup	
	4. Start Operator Interface	
	5. Connecting AMRF Systems	
	6. Bringing Down the IMDAS	
	7. Logging Out	
V.	Database Mailbox Prefixes	10
	1. Horizontal Workstation	
	2. Inspection Workstation	
	3. Cell	
	4. Vertical Workstation	

5. Cleaning and Deburring Workstation
6. Material Handling Workstation
7. Process Planning

List of References	12
Reader Comment Form	13

INTEGRATED MANUFACTURING DATA ADMINISTRATION SYSTEM
OPERATIONS MANUAL

List of Figures

Figure 1. Amrf Floor Layout

11

INTEGRATED MANUFACTURING DATA ADMINISTRATION SYSTEM OPERATIONS MANUAL

I. INTRODUCTION

1. PURPOSE OF THIS DOCUMENT

The purpose of this manual is to provide instructions to train an operator to run Version 1.3 of the Integrated Manufacturing Data Administration System (IMDAS). The IMDAS is an ongoing research effort supporting data access throughout the Automated Manufacturing Research Facility (AMRF) [2].

2. MODES OF OPERATION

The mode generally used during operation of the IMDAS is the Foreground mode; this mode gives the operator a more visual layout of the IMDAS. The Background mode is available should a Sun workstation not be in service.

3. CONTACTS FOR ERRORS

If the operator encounters any error, he/she should contact one of the principal operators/researchers of the Integrated Systems Group for assistance at x3557.

4. CONVENTIONS USED IN THIS DOCUMENT

4.1. Keyboard Conventions

4.1.1. Carriage Return

As a general practice, after each command, enter a carriage return <cr>.

4.1.2. Delete

In case of a typographical error, use the delete key to erase.

4.2. Sun References

Throughout this manual references to a 'Sun workstation' are made. These are aliases for Sun Microsystems and Sun Workstations which are trademarks of Sun Microsystems, Inc.

4.3. VAX References

Throughout this manual references to the 'VAX' are made. These are aliases for the CME::VAX.

4.4. NETWORK References

Throughout this manual references to the 'NETWORK' system are made. These are aliases for the Automated Manufacturing Research Facility Network System. To run the Network System refer to "AMRF Network Communications" [1].

II. DEVICES NEEDED

The following is a list of DEVICES needed for operating the IMDAS in the Foreground and Background modes. The DEVICES mentioned below are located in Control Room II of the Shops Bldg. (An AMRF floor plan is appended to the back of this manual.)

1. FOREGROUND MODE

A Sun microsystem is needed in addition to the NETWORK system.

2. BACKGROUND MODE

A vt100 terminal linked to the VAX via a net is needed in addition to the NETWORK system.

III. FOREGROUND MODE

This section describes how to bring up IMDAS in Foreground mode using a Sun workstation.

1. SUN STARTUP

1.1. Lockscreen Mode

If the Sun is in lockscreen or screen-saver mode (i.e. the background of the screen is blacked out and an icon (picture) is flashing about the screen), press the left mouse button or a key on the keyboard to quit.

1.2. Power Off

If the Sun is completely turned off, turn it on via two main power switches:

- (1) Turn the base pedestal switch to position (1).
- (2) Turn the terminal (display screen) switch to position (1).

At this point the Sun should be either at a login prompt or rebooting itself. The user will notice a reboot in process if he sees the word "boot" being displayed. Should the SUN get stuck at a question mark (?) during the boot process, an expert should be notified at the number given in Section 3 of the Introduction of this manual.

2. LOGIN

At the Sun login prompt, type 'imdask'.

NOTE: At this point, ask the supervisor or NETWORK operator if the NETWORK is ready for processing. If so, proceed to the next step, IMDAS STARTUP; otherwise, wait until the NETWORK is ready for processing.

3. IMDAS STARTUP

The system will give the following prompt:

Do you wish to bring up the VAX imdas? (y/n)

Enter 'y' to bring up the imdas.

4. CONNECTING AMRF SYSTEMS

The IMDAS automatically connects to all the AMRF systems and displays the connected command and status mailboxes for each system in the window labelled 'realuser' (located at the top left of the screen) [1]. To decipher the mailbox names listed, i.e., (for example):

```
name: DS_PP_CMD
name: DS_PP_STS
```

look at the mailbox prefix (for the above example - DS_PP) and Section V, Database Mailbox Prefixes. In the above example, the prefix refers to the Process Planning system.

Note: The IMDAS is ready for transaction interaction when the messages in the windows have stopped scrolling.

5. BRINGING DOWN THE IMDAS

- (1) Type a 'q' at the realuser prompt.
- (2) Type 'exit' at the VAX DEBUG prompt DBG>.
- (3) Move the Sun mouse pointer to each window, except the 'console' window (located at the top right of the screen), and type a '<ctrl-c>' (hold the control key down while depressing the 'c' character).
- (4) Move the Sun mouse pointer to each window, except the 'console' window, and type 'exit'.

Note: In the window labelled 'ctgms' (located at the third right of the screen), after the above (4) 'exit' has been typed, type an additional 'exit' at the VAX DEBUG prompt DBG>.

6. LOGGING OUT

6.1. Logging Out Connections to the VAX

Move the Sun mouse pointer to each of the windows, except the 'console' window, and type 'logout'.

All the windows on the screen should vanish except the 'console' window.

6.2. Logging Out of the IMDAS Sun Account

- (1) Move the Sun mouse pointer to the gray area.

- (2) While depressing the right mouse button, move the Sun mouse pointer to the 'Basic Tools ->' arrow (another menu should pop up), and keeping the right mouse button depressed, move the Sun mouse pointer to the 'Exit Suntools' selection on the second menu. Release the button.

The Suntools screen should disappear and the directory prompt:

```
('machine name')imdas:
```

should be visible.

- (3) Type 'logout'.

The login prompt should now be visible.

IV. BACKGROUND MODE

This section describes how to bring up IMDAS in BACKGROUND mode using a vt100 terminal.

1. LOGIN

At the VAX login prompt, type AMRFINT1, password AMRF.

2. ENTER IMDAS DIRECTORY

At the directory prompt:

directory (NET, IMDAS, TEKDISP, other):

Type 'imdas' to enter the IMDAS subdirectory.

NOTE: At this point, ask the supervisor or NETWORK operator if the NETWORK is ready for processing. If so, proceed to the next step, BACKGROUND STARTUP; otherwise, wait until the NETWORK is ready for processing.

3. BACKGROUND STARTUP

Type '@bgimdas amrftst1'.

The following processes should be listed, followed by a system prompt (\$):

```

TM
BSE
DSE
CTFS
CTPPS
CTING
CTGMSRIM

```

4. START OPERATOR INTERFACE

Type 'run/nodebug realuser'.

The following prompt should be listed:

```

imdas, connect, read, write, declare, sync, print-style,
finish, @file:

```

5. CONNECTING AMRF SYSTEMS

NOTE: For each AMRF system connection, steps (1) thru (3) must be made.

(1) At the prompt, type 'c' for connect.

(2) At the mailbox prompt:

mailbox prefix (<cr> for "COKE"):

Type the appropriate mailbox prefix.

For example, for Inspection Workstation, the mailbox prefix is: DS_IWS. A list of the mailbox prefixes for each workstation is located at the back of this manual in Section V, Database Mailbox Prefixes. Ask the supervisor or NETWORK operator which AMRF systems are to be connected. NOTE: Mailbox prefixes must be typed in CAPITALS.

(3) At the station name prompt:

station name (<cr> for "VAX"):

Type a carriage return <cr>.

(4) Type 's' for sync.

(5) Type 'r' for read; this will list back the command and status mailboxes of each AMRF system that has been connected, enabling the operator to check for typographical errors. For example, connecting the Process Planning system with the following mailbox prefix:

DS_PP

connects the system's appropriate command and status mailboxes:

name: DS_PP_CMD

name: DS_PP_STS

If an error is discovered, redo steps (1) thru (5) until connection is established.

NOTE: The system is now ready for transaction interaction.

6. BRINGING DOWN THE IMDAS

(1) Type a 'q' at the realuser prompt.

- (2) At the system prompt, type '@killimdas'. After a short period of time all the processes should vanish.

7. LOGGING OUT

To disconnect the session from the VAX, type 'logout'.

V. DATABASE MAILBOX PREFIXES

This section gives a listing of the Database Mailbox prefixes for each workstation. These are the current prefixes as listed in the November 29, 1986 document of Mailbox Scripts.

1. HORIZONTAL WORKSTATION

Workstation Controller Bucket - DS_HWS
Machine Tool Controller Bucket - DS_HMTC
Material Buffering Device Bucket - DS_HMBD
RCS Robot Controller Bucket - DS_HRCS
Vision System Bucket - DS_HVIS

2. INSPECTION WORKSTATION

Workstation Controller Computer - DS_IWS
Coordinate Measuring Machine Computer - DS_ICMM
Robot Controller Computer - DS_IRCS
Surface Roughness Instrument Computer - DS_ISR1

3. CELL

Interface - DS_C

4. VERTICAL WORKSTATION

Sun Communications Server - DS_VWS

5. CLEANING AND DEBURRING WORKSTATION

Sun Communications Server - DS_DWS

6. MATERIAL HANDLING WORKSTATION - DS_MHS

7. PROCESS PLANNING - DS_PP




Figure 1. AMRF Floor Layout

List of References

[1] Rybczynski, S., Barkmeyer, E. J., Wallace, E. K., Strawbridge, M. L., Libes, D. E., Young, C. V., "AMRF Network Communications", to be published as an NBSIR.

[2] Furlani, C., Editor, "Integrated Manufacturing Data Administration System (IMDAS)", to be published as an NBSIR.

READER COMMENT FORM

Document Title Integrated Manufacturing Data Administration
 System Operations Manual

This document is one in a series of publications which document research done at the National Bureau of Standards' Automated Manufacturing Research Facility from 1981 through March, 1987.

You may use this form to comment on the technical content or organization of this document or to contribute suggested editorial changes.

Comments: _____

If you wish a reply, give your name, company, and complete mailing address: _____

What is your occupation? _____

NOTE: This form may not be used to order additional copies of this document or other documents in the series. Copies of AMRF documents are available from NTIS.

Please mail your comments to: AMRF Program Manager
 National Bureau of Standards
 Building 220, Room B-111
 Gaithersburg, MD 20899

U.S. DEPT. OF COMM. BIBLIOGRAPHIC DATA SHEET <i>(See instructions)</i>	1. PUBLICATION OR REPORT NO. NBSIR 88-3743	2. Performing Organ. Report No.	3. Publication Date APRIL 1988
4. TITLE AND SUBTITLE Integrated Manufacturing Data Administration System Operations Manual			
5. AUTHOR(S) Deborah A. Nickerson			
6. PERFORMING ORGANIZATION <i>(If joint or other than NBS, see instructions)</i> NATIONAL BUREAU OF STANDARDS DEPARTMENT OF COMMERCE WASHINGTON, D.C. 20234		7. Contract/Grant No. 8. Type of Report & Period Covered	
9. SPONSORING ORGANIZATION NAME AND COMPLETE ADDRESS <i>(Street, City, State, ZIP)</i>			
10. SUPPLEMENTARY NOTES <input type="checkbox"/> Document describes a computer program; SF-185, FIPS Software Summary, is attached.			
11. ABSTRACT <i>(A 200-word or less factual summary of most significant information. If document includes a significant bibliography or literature survey, mention it here)</i> This is an operator's manual for the Integrated Manufacturing Data Administration System (IMDAS) of the Automated Manufacturing Research Facility (AMRF). The IMDAS is designed to provide the control systems of the AMRF access to the data necessary to support the design, planning, manufacturing, and inspection of parts. This manual describes the necessary steps to place the IMDAS into service within the AMRF.			
12. KEY WORDS <i>(Six to twelve entries; alphabetical order; capitalize only proper names; and separate key words by semicolons)</i> IMDAS, AMRF, CIM			
13. AVAILABILITY <input checked="" type="checkbox"/> Unlimited <input type="checkbox"/> For Official Distribution. Do Not Release to NTIS <input type="checkbox"/> Order From Superintendent of Documents, U.S. Government Printing Office, Washington, D.C. 20402.		14. NO. OF PRINTED PAGES 19	
<input checked="" type="checkbox"/> Order From National Technical Information Service (NTIS), Springfield, VA. 22161		15. Price \$9.95	

