

National Bureau of Standards
Library, E-01 Admin. Bldg.

JUN 16 1970

NBS TECHNICAL NOTE 529

Determination of Oxygen Concentration in Silicon and Germanium by Infrared Absorption

UNITED STATES
DEPARTMENT OF
COMMERCE
PUBLICATION



U.S.
DEPARTMENT
OF
COMMERCE

National
Bureau
of
Standards

NATIONAL BUREAU OF STANDARDS

The National Bureau of Standards was established by an act of Congress March 3, 1901. Today, in addition to serving as the Nation's central measurement laboratory, the Bureau is a principal focal point in the Federal Government for assuring maximum application of the physical and engineering sciences to the advancement of technology in industry and commerce. To this end the Bureau conducts research and provides central national services in four broad program areas. These are: (1) basic measurements and standards, (2) materials measurements and standards, (3) technological measurements and standards, and (4) transfer of technology.

The Bureau comprises the Institute for Basic Standards, the Institute for Materials Research, the Institute for Applied Technology, the Center for Radiation Research, the Center for Computer Sciences and Technology, and the Office for Information Programs.

THE INSTITUTE FOR BASIC STANDARDS provides the central basis within the United States of a complete and consistent system of physical measurement; coordinates that system with measurement systems of other nations; and furnishes essential services leading to accurate and uniform physical measurements throughout the Nation's scientific community, industry, and commerce. The Institute consists of an Office of Measurement Services and the following technical divisions:

Applied Mathematics—Electricity—Metrology—Mechanics—Heat—Atomic and Molecular Physics—Radio Physics²—Radio Engineering²—Time and Frequency²—Astrophysics²—Cryogenics.²

THE INSTITUTE FOR MATERIALS RESEARCH conducts materials research leading to improved methods of measurement standards, and data on the properties of well-characterized materials needed by industry, commerce, educational institutions, and Government; develops, produces, and distributes standard reference materials; relates the physical and chemical properties of materials to their behavior and their interaction with their environments; and provides advisory and research services to other Government agencies. The Institute consists of an Office of Standard Reference Materials and the following divisions:

Analytical Chemistry—Polymers—Metallurgy—Inorganic Materials—Physical Chemistry.

THE INSTITUTE FOR APPLIED TECHNOLOGY provides technical services to promote the use of available technology and to facilitate technological innovation in industry and Government; cooperates with public and private organizations in the development of technological standards, and test methodologies; and provides advisory and research services for Federal, state, and local government agencies. The Institute consists of the following technical divisions and offices:

Engineering Standards—Weights and Measures—Invention and Innovation—Vehicle Systems Research—Product Evaluation—Building Research—Instrument Shops—Measurement Engineering—Electronic Technology—Technical Analysis.

THE CENTER FOR RADIATION RESEARCH engages in research, measurement, and application of radiation to the solution of Bureau mission problems and the problems of other agencies and institutions. The Center consists of the following divisions:

Reactor Radiation—Linac Radiation—Nuclear Radiation—Applied Radiation.

THE CENTER FOR COMPUTER SCIENCES AND TECHNOLOGY conducts research and provides technical services designed to aid Government agencies in the selection, acquisition, and effective use of automatic data processing equipment; and serves as the principal focus for the development of Federal standards for automatic data processing equipment, techniques, and computer languages. The Center consists of the following offices and divisions:

Information Processing Standards—Computer Information—Computer Services—Systems Development—Information Processing Technology.

THE OFFICE FOR INFORMATION PROGRAMS promotes optimum dissemination and accessibility of scientific information generated within NBS and other agencies of the Federal Government; promotes the development of the National Standard Reference Data System and a system of information analysis centers dealing with the broader aspects of the National Measurement System, and provides appropriate services to ensure that the NBS staff has optimum accessibility to the scientific information of the world. The Office consists of the following organizational units:

Office of Standard Reference Data—Clearinghouse for Federal Scientific and Technical Information¹—Office of Technical Information and Publications—Library—Office of Public Information—Office of International Relations.

¹ Headquarters and Laboratories at Gaithersburg, Maryland, unless otherwise noted; mailing address Washington, D.C. 20234.

² Located at Boulder, Colorado 80302.

³ Located at 5285 Port Royal Road, Springfield, Virginia 22151.

UNITED STATES DEPARTMENT OF COMMERCE
Maurice H. Stans, Secretary
NATIONAL BUREAU OF STANDARDS • Lewis M. Branscomb, Director



TECHNICAL NOTE 529

ISSUED MAY 1970

Nat. Bur. Stand. (U.S.), Tech. Note 529, 21 pages (May 1970)
CODEN: NBTNA

Determination of Oxygen Concentration in Silicon and Germanium by Infrared Absorption

W. R. Thurber

Electronic Technology Division
Institute for Applied Technology
National Bureau of Standards
Washington, D.C. 20234



NBS Technical Notes are designed to supplement the Bureau's regular publications program. They provide a means for making available scientific data that are of transient or limited interest. Technical Notes may be listed or referred to in the open literature.



Determination of Oxygen Concentration in Silicon and Germanium by Infrared Absorption

W. R. Thurber

Infrared absorption measurements were made at room temperature, 80 K, and 20 K to determine the absorption coefficient of oxygen in silicon and germanium single crystals. A study was done to compare the results of four experimental methods, which involved both absolute and difference procedures.

Sources of error were identified, including that due to calculating the absorption coefficient with an approximate equation which neglects multiple internal reflections. Measurements made on the same specimen at several temperatures give additional data on the relation of oxygen concentration to absorption coefficient at low temperatures.

Key Words: absorption coefficient; infrared absorption; germanium; methods of measurement; oxygen in germanium; oxygen in silicon; silicon

1. INTRODUCTION

This report summarizes results on the oxygen concentration of silicon and germanium single crystals determined by infrared absorption measurements at room temperature, 80 K, and 20 K. An important part of the report is an experimental comparison of absorption measurements made by various methods on silicon slices. The procedures followed in making the absorption measurements were essentially the same as those given in various ASTM documents [1].

* The instrument used for most of the work was a Perkin-Elmer Model 337 double beam, infrared grating spectrophotometer, linear in wavelength with adjustable slit width. A scale expansion accessory added to this instrument was available for most of the measurements. Also a slower scan motor (72 min to cover the range 7.5 to 25 μ m) was installed for recording narrow absorption bands. Occasionally spectra were run on other instruments at NBS for comparison with those obtained on this spectrophotometer.

* The commercial instrument is identified in this paper in order to specify adequately the experimental procedure. In no case does such identification imply recommendation or endorsement by the National Bureau of Standards, nor does it imply that the equipment identified is necessarily the best available for the purpose.





Figure 1. Dewar system used in sample beam of spectrophotometer. A photograph of the germanium specimen (S) mounted on a copper plate (P) attached to a flange (F) at the end (E) of the inner flask is shown in the inset. A thermocouple (T) is bonded to the side of the specimen.


The absorption coefficient of oxygen increases with a decrease in temperature, so smaller concentrations of the impurity can be detected when the specimens are cooled. Double Dewar flasks were used to cool both the sample and reference specimens to temperatures of 80 K (liquid nitrogen) and 20 K (liquid helium in the inner flask).

The Dewar system for the sample beam shown in Fig. 1 is patterned after an optical cell designed by H. N. Hersh [2]. The Dewar system for the reference beam was similar but smaller in diameter to fit the available space in the spectrophotometer. Potassium bromide windows, 5-mm thick, were secured to the flanged openings with a varnish which provided the necessary vacuum seal. The specimens were mounted on copper plates with the aid of spring clips and conductive silver paste. This assured good thermal contact in order to dissipate heat from the specimen due to the incident radiation and the room temperature environment. As shown in the inset in Fig. 1, the plate was fastened to a flange soldered onto the copper seal at the end of the inner flask. The alignment was such that the hole in the plate through which the radiation passed was in the center of the Dewar windows. It was found that if the flask were positioned so that the copper plate faced the incoming radiation, then lower temperatures were reached than when the specimen faced the incident beam. This was attributed to the more direct path provided by the copper plate in conducting heat to the liquid helium. A thermocouple was glued to the side of the specimen (silver paste was used at the junction for better thermal contact) and the leads emerged from the Dewar system through the joint at the top of the inner flask.

2. EXPERIMENTAL PROCEDURES

There are several procedures by which the absorption coefficient due to an impurity in a crystal can be determined. All of the four methods investigated in this study should yield the same value for the absorption coefficient if the measurements are carefully done, the instrument is functioning properly, the correct equation is used, and the proper correction is made for lattice absorption.

The *absolute transmittance method* follows the procedure given in ASTM Method F45-64T [1]. The spectrophotometer is initially adjusted so that 100 percent transmittance is read with air in both beams and 0 percent is recorded with the sample beam blocked. Then the specimen, with polished, parallel faces, is placed in the sample beam and the spectrum recorded. An example is shown in Fig. 2a. The minimum percent transmittance T_m is noted for the 9- μ m band and the absorption coefficient is determined^m by computations involving the transmission equation which is discussed in Section 3. For all but the most accurate work, a graph in the ASTM method can be used in lieu of the computations. The oxygen concentration is obtained from a calibration curve in the document. This procedure has the disadvantage that the absolute transmittance is used which requires correct 0 and 100 percent transmittance readings and necessitates good preparation of the specimen surfaces to keep scattered light to a minimum. Any surface films which affect the reflectivity will introduce errors. Also the specimen resistivity must be greater than



a b c d

Figure 2. These spectra illustrate the four methods used for determining the absorption coefficient of the 9- μ m oxygen band in silicon. (a) Absolute transmittance recorded following procedure in ASTM Method F45-64T. (b) Relative transmittance recorded with air in the reference beam. Shown are the T_m and T_0 used to calculate the absorption coefficient. (c) Relative transmittance traces for the single-beam difference method. An oxygen-free slice of the same thickness as the test specimen is run in the sample beam to obtain T_m . (d) Double-beam difference recording with an oxygen-free slice in the reference beam. The sample specimen for all of the spectra was a 5-mm thick slice from crystal L42Mx. The reference slice was from crystal 10190-4.

1 Ω -cm; otherwise free carrier absorption will reduce the transmittance.

In the *air reference method*, the spectrum is also obtained with air in the reference beam of the spectrophotometer and then a straight baseline is drawn tangent to the peaks in transmittance on each side of the 9- μ m absorption. In the example shown in Fig. 2b an attenuator was used in the reference beam to move the trace higher on the transmittance scale and thereby magnify the recording. The total absorption coefficient is calculated from the equation

$$T_m = T_o e^{-\alpha' x} \quad (1)$$

where

- T_m = transmittance minimum for the impurity absorption peak,
- T_o = baseline transmittance measured at the same wavelength as T_m ,
- α' = absorption coefficient, and
- x = thickness of slice.

To obtain the absorption coefficient due to oxygen, a lattice contribution is subtracted from the total coefficient.

In the *single-beam difference method* (or reference standard method [3]) the test specimen and an oxygen-free crystal of the same thickness and surface finish are consecutively recorded on the same paper as shown in Fig. 2c. In Eq. (1), which is used for the calculations, T_m is the relative transmittance of the specimen at the impurity absorption peak and T_o is the transmittance of the oxygen-free reference slice at the same wavelength. The absorption coefficient α' is that due to oxygen only as using a reference crystal to obtain T_o eliminates the lattice absorption.

In the *double-beam difference procedure*, the spectrum is obtained with the test specimen in the sample beam and an oxygen-free slice of the same thickness in the reference beam. As illustrated by Fig. 2d, this method cancels out the lattice absorption. The baseline T_o is drawn as a straight line coincident with the transmittance trace on both sides of the absorption band. The flat baseline allows the trace to be made near the top of the transmittance scale, thereby giving a peak size which is larger than that obtainable by the other methods. Differences in free carrier absorption between the two slices will give an irregular or sloping baseline, but will have little effect on the impurity peak. Equation (1) is used to find the absorption coefficient due to oxygen. This difference procedure is generally the most accurate method, especially for small impurity concentrations, and may be the only one with the required sensitivity.

Table 1. Results of measurements of the absorption coefficient of oxygen in silicon specimens by different methods

Crystal number	Specimen thickness	Absolute		Air reference			Single beam difference		Double beam difference			
		α	Std. dev.	α^a	Std. dev.	α^b	α'	Std. dev.	α	α'	Std. dev.	α
	cm	cm ⁻¹		cm ⁻¹		cm ⁻¹	cm ⁻¹		cm ⁻¹		cm ⁻¹	cm ⁻¹
R818A	0.1036	2.03	0.08	2.21	0.04	2.22	2.38	0.03	2.10	2.69	0.06	2.39
	.201	2.08	.16	1.99	.05	2.09	2.12	.02	1.94	2.44	.12	2.24
	.500	2.38	.15	2.09	.09	2.31	2.29	.09	2.22	2.39	.07	2.32
L42Mx	.1037	1.24	.03	1.33	.03	1.43	1.45	.06	1.27	1.63	.03	1.43
	.201	1.35	.19	1.29	.04	1.44	1.41	.03	1.27	1.61	.11	1.46
	.500	1.39	.04	1.16	.02	1.40	1.35	.02	1.29	1.46	.04	1.40
1105	.177	1.21	.07	1.15	.05	1.30	1.23	.01	1.10	1.47	.05	1.32
1174	.201	1.15	.10	1.12	.07	1.28	1.31	.06	1.18	1.40	.04	1.26
602826	.185	3.65	.12	3.42	.16	3.43	3.60	.14	3.33	3.96	.03	3.68

^a α' is the oxygen absorption coefficient calculated from the approximate equation $T_m = T_0 e^{-\alpha' x}$.

^b α is the oxygen absorption coefficient calculated using the complete transmission equation and includes corrections discussed in the text.

Table 2. Ratio of oxygen absorption coefficient at about 80 K to that at room temperature and oxygen concentration for silicon specimens

Specimen	Temperature	α_{80}	Temperature	α_{300}	α_{80}/α_{300}	Oxygen ^a
	K	cm ⁻¹	K	cm ⁻¹		atoms/cm ³
21-157-4-2	79	0.806	308	0.383	2.1	1.84×10^{17}
1174	80	3.03	308	1.26	2.4	6.05
reference [7] ^b	78	3.4	297	1.8	1.9 ^c	8.6
reference [4] ^d	90	4.4	room	2.6	1.7	12.5

^a Calibration equation: oxygen atoms/cm³ = $4.8 \times 10^{17} \alpha_{300}$.

^b Background absorption was estimated.

^c Ratio 2.1 when slit width correction applied.

^d Slit width not given.

3. COMPARISON OF METHODS FOR SILICON

Absorption measurements were made on several silicon specimens using each of the four methods given in Section 2. The results are given in Table 1. Each value listed is the average of about five recordings of the absorption band and an estimated standard deviation of the mean was calculated from the individual measurements. Also listed are the values after corrections were made for the known errors in the last three methods. Two corrections are necessary. The first involves the error introduced when the approximate equation, Eq. (1), which neglects multiple internal reflections, is used instead of the more complete equation

$$I = \frac{I_i (1-R)^2 e^{-\alpha x}}{1-R^2 e^{-2\alpha x}} \quad (2)$$

where I = transmitted intensity measured at wavelength of impurity absorption peak,
 I_i = radiation intensity on specimen at normal incidence,
 R = reflectivity of a single air-crystal interface,
 α = absorption coefficient, and
 x = thickness of slice.

The calculations relating the absorption coefficient α determined by Eq. (2) with the α' of Eq. (1) for both air reference and difference methods are outlined in the appendixes. To determine when Eq. (1) can be used without appreciable error (10 %), calculations were made for a range of oxygen absorption coefficients and specimen thicknesses using constants appropriate for germanium and silicon. Graphs of the results are given in the appendixes.

The second correction applies only to the air reference method and involves the baseline intensity which is used in the approximate equation. The baseline tangent to the peaks in transmittance on each side of the oxygen band does not place all of the lattice absorption (0.8 cm^{-1}) under the baseline, but only that amount in the lattice peak. From the work of Kaiser, Keck, and Lange [4], it is evident that the excluded lattice absorption is about half of the total value. Thus it would be more appropriate to subtract 0.4 cm^{-1} , instead of 0.8 cm^{-1} , when determining the oxygen absorption coefficient by the air reference method. Consequently 0.4 cm^{-1} was added to each of the absorption coefficients in the corrected column for the air reference measurements.

The corrected absorption coefficients as determined by the four methods (Table 1) are in reasonable agreement. If 0.4 cm^{-1} had not been added to each of the air reference values, all of these would be much smaller than those obtained from the other methods. Other trends are: (1) The double-beam difference method always gives a larger coefficient than the single-beam difference method, and (2) for the absolute transmittance method the absorption coefficient varies systematically with specimen thickness, with thicker specimens in better agreement with the

other methods. The latter trend is not unexpected as the various errors (such as 0 and 100 percent transmittance settings and surface preparation) are relatively more important for a thin specimen than for a thick one.

Another source of error in the measurements was the non-linearity of the spectrophotometer as a function of baseline transmittance. This error is most readily observed in the double-beam difference method by running the specimens at a high transmittance baseline and then repeating the scan at a lower transmittance baseline (achieved by adjusting the 100 percent control). Consistently, it was found that the absorption coefficient determined from a baseline of 70 to 80 percent transmittance was several percent smaller than that calculated from a 90 to 100 percent baseline. This result may not be typical as the effect was somewhat smaller on another instrument of similar design.

Another factor which may affect the results is the spectral slit width of the spectrophotometer and its relation to the full width at half maximum intensity (FWHM) of the impurity peak. The spectral slit width is the mechanical width of either the exit or the entrance slit, whichever is the larger, divided by the linear dispersion in the exit slit plane. The spectral slit width must be narrow enough so that the full peak height will be reproduced. The oxygen absorption band in silicon has a Gaussian profile at room temperature with a wide FWHM so that the slit setting of the instrument is not critical. The FWHM observed in this work was 35 cm^{-1} and values quoted in the literature are 30 cm^{-1} [5] and 32 cm^{-1} [6]. The FWHM determined from the spectra of Hrostowski and Kaiser [7] was about 32 cm^{-1} . The appropriate ASTM document gives 32 cm^{-1} . At 80 K the oxygen band is narrow so correspondingly narrow instrument slit widths must be used. The FWHM at 80 K found in this work was 20 cm^{-1} and values from the literature are also about 20 cm^{-1} [4,7]. The ASTM value for 80 K is likewise 20 cm^{-1} .

When recording sharp absorption bands with narrow slit widths, it is important to scan the wavelength range of interest at a slow speed. Otherwise the peak height will be attenuated or, with a fast pen response, overshoot may occur due to the rapid change of absorption. A slow scan speed will improve the signal to noise ratio as the pen response can be reduced without loss of detail. The reproducibility of the peak shape is a useful criterion in determining the quality of the recording. When the peak is narrow, abscissa expansion is necessary to determine its shape and FWHM. The expansion was achieved by using an external recorder in conjunction with the 72 min scan speed of the spectrophotometer. Ordinate expansion was also used when the peak height was small.

4. OXYGEN CONCENTRATION AND TEMPERATURE DEPENDENCE OF ABSORPTION COEFFICIENT FOR SILICON

Recent measurements [8] on the relation between absorption coefficient and oxygen concentration are in disagreement with the earlier work of Kaiser and Keck [9], which serves as the calibration for ASTM method

F-45. The new equation relating oxygen content to the absorption coefficient at 9 μm [oxygen atoms/cm³ = $4.8 \times 10^{17} \alpha$ (cm⁻¹)] gives about twice the oxygen that is obtained by use of Kaiser and Keck's results. Infrared absorption measurements and the lithium precipitation method [10] give the same amount of oxygen in silicon crystals if the new calibration is used for the infrared work. Also the oxygen content in silicon as determined by ³He activation [11] was about twice that found by infrared absorption. The calibration equation used for the absorption analysis was not given, but the Kaiser and Keck relation was probably used as it has been the customary one. The use of the new calibration would bring the oxygen content as determined by absorption into close agreement with that found by ³He activation.

As mentioned in the introduction, the height of the absorption peak increases with a decrease in temperature. At room temperature the absorption appears as a single peak, but when the specimen is cooled two peaks emerge which are well resolved at 80 K [7]. At 20 K, the peak which was the stronger of the two at 80 K is now the weaker one. The stronger absorption peak at 18 K has a coefficient about three times as large as that of the broad peak at 297 K [7]. On the one specimen measured at 20 K in the present work, a value of about 5 was found for the ratio α_{20}/α_{300} . Pajot [5] measured specimens cooled to 8 K using a narrow spectral slit width (0.32 cm⁻¹) and found that α_8/α_{300} was about 25. Since the absorption coefficient is this strong at liquid helium temperatures, it is possible to determine oxygen concentrations down to about 1×10^{14} atoms/cm³. The disadvantages of the procedure are the narrow slit width required to obtain the full peak height and the low temperature which must be consistently achieved.

Measurements at 80 K are of special interest as the ASTM Method F121-70T includes a calibration for this temperature. Table 2 lists absorption coefficients obtained at temperatures near 80 K and 300 K and the ratio calculated from the coefficients. Also included is the oxygen concentration for each specimen based on the coefficient at 300 K. For the literature references the data were taken from the published graphs, and the background absorption for an oxygen-free slice was subtracted to get only the absorption coefficient due to oxygen. The double-beam difference method was used for the present measurements at room temperature and at 80 K. A gold-cobalt versus chromel thermocouple was used to determine the temperature. The value of 308 K given for nominal room temperature measurements was the temperature obtained by attaching a thermocouple directly to one of the specimens. Thus the heating of the specimens by the infrared beam can give some error if the calibration is based on results at 300 K. The work of Hrostowski and Kaiser [7] can be extrapolated above 300 K to get an approximate idea of the change in absorption coefficient with temperature. It is fortunate that α varies slowly with temperature so that heating of the specimens will not be a major source of error.

Hrostowski and Kaiser state that their absorption coefficients have a maximum error of 10 percent in regions of strong absorption because of the slit widths which were used in recording the narrow bands. Since at

room temperature the band is wide, the error occurs only for 80 K measurements and a correction of 10 percent in the ratio α_{80}/α_{300} of Table 2 increases it to 2.1. The slit width used in the present work was sufficiently narrow so that any corrections would be only a few percent. The absorption coefficient calculations were made with Eq. (2) using 0.4 cm^{-1} for the lattice absorption coefficient at 80 K and 0.2964 for the reflectivity.

On the basis of this work and various ASTM round robins, it appears that ± 20 percent is a realistic figure to expect for the multi-laboratory precision for determination of oxygen in silicon by infrared absorption.

5. MEASUREMENTS ON GERMANIUM

Procedures similar to those described for silicon may be used for measurements on germanium. There is some disagreement on the calibration equation relating the absorption coefficient of the $11.7\text{-}\mu\text{m}$ band to the interstitial oxygen concentration. Kaiser and Thurmond [12] used vacuum fusion determinations made with an iron bath to calibrate their infrared absorption measurements and found that oxygen atoms/ $\text{cm}^3 = 0.5 \times 10^{17} \alpha \text{ (cm}^{-1}\text{)}$. Millett, Wood, and Bew [13] repeated the work and obtained inconsistent results with an iron bath. However, when they used a platinum bath their data was consistent to about 20 percent of the total oxygen content. The calibration found was that oxygen atoms/ $\text{cm}^3 = 1.25 \times 10^{17} \alpha \text{ (cm}^{-1}\text{)}$. This is the same factor that Bloem, Haas, and Penning [14] derived, but this is coincidental, as they based their calculation on silicon data which is now considered inaccurate. Fox [15] determined the oxygen content of germanium by the lithium precipitation technique and compared the results with infrared absorption measurements on specimens cooled to 20 K. The calibration obtained was that oxygen atoms/ $\text{cm}^3 = 3.1 \times 10^{16} \alpha \text{ (cm}^{-1}\text{)}$. This is in good agreement with the results of Millett, et al., as data on the variation of the absorption coefficient with temperature show that the coefficient is about four times larger at 20 K than at 300 K.

The free carrier absorption coefficient per unit carrier concentration is about ten times higher in *p*-type than in *n*-type germanium [16]. The absorption cross section in *p*-type material is $7 \times 10^{-16} \text{ cm}^2$ at $11.7 \mu\text{m}$ for both 300 and 80 K [16-18], and the absorption coefficient is the product of the cross section and the carrier concentration. The data from measurements on many specimens at room temperature, 80 K, and 20 K were analyzed to compare the expected values for the background absorption coefficient with the experimental ones. The coefficients varied from 0.07 to 0.15 cm^{-1} , independent of temperature, for *p*-type specimens with carrier concentrations in the range 4×10^{13} to $2 \times 10^{14} \text{ cm}^{-3}$. The correction for multiple reflections is fairly insensitive to the value used for the background absorption coefficient, so 0.1 cm^{-1} was used for the specimens included in this report as they all had carrier concentrations below $2 \times 10^{14} \text{ cm}^{-3}$. This is also the value used by Kaiser and Thurmond [12] for room temperature measurements on a specimen with low carrier density.

Table 3. Absorption coefficient and FWHM as a function of temperature for the 11.7 μm oxygen band in germanium specimen NBS-91 (thickness 1.19 cm)

Temp.	Spectral Slit width	α'	Std. dev.	R	α	FWHM	Peak area ($\alpha \cdot \text{FWHM}$)
K	cm^{-1}	cm^{-1}			cm^{-1}	cm^{-1}	cm^{-2}
305	3.5	0.0081	0.0006	0.360	0.0066	4.7	0.031
229	3.5	.012	.002	.358	.0097	4.7	.046
153	3.5	.017	.002	.356	.014	3.6	.050
81	3.5	.027	.002	.354	.022	3.5	.077
81	2.5	.028	.005	.354	.023	2.8	.064
23	3.5	.030	.002	.352	.025	2.8	.070
23	2.5	.039	.003	.352	.032	2.6	.083

Table 3 lists measurements at several temperatures of the absorption coefficient and FWHM of the oxygen band in specimen NBS-91. The double-beam difference method was used and the calculations were corrected to include the effects of multiple internal reflections. The absorption coefficient obtained at 23 K with the narrow slit width is significantly larger than the one found using the wider slit. The area under the absorption band increases with a decrease in temperature. The FWHM at room temperature may be concentration dependent as measurements on several specimens indicated that the FWHM increased as the oxygen concentration increased. The literature references give values for FWHM of 5 cm^{-1} [14] and 6 cm^{-1} [19], whereas the appropriate ASTM document lists 8 cm^{-1} [1]. Bloem, Haas, and Penning [14] give 3 cm^{-1} for the FWHM at 77 K, and a value of 2.8 cm^{-1} is obtained from the work of Kaiser [19]. At 5 K a value of 2.5 cm^{-1} is determined from spectra of Kaiser. All of the low temperature FWHM, including those in Table 3, may be slightly greater than the true ones because of the relatively wide slit widths used.

Table 4 gives the temperature variation of the absorption coefficient of the 11.7 μm oxygen band. Literature values, in addition to the data obtained in this work, are included. Room temperature was estimated as 305 K to include heating by the infrared beam. The low temperature values were calculated from thermocouple readings for each specimen. All measurements were made by the double-beam difference method and were

Table 4. Temperature dependence of the absorption coefficient of oxygen in germanium specimens

Specimen	Thickness	Room temperature		Liquid nitrogen		Liquid helium		$\frac{\alpha_{80}}{\alpha_{300}}$	$\frac{\alpha_{20}}{\alpha_{300}}$
		T	α	T	α	T	α		
	cm	K	cm ⁻¹	K	cm ⁻¹	K	cm ⁻¹		
NBS-01	0.844	305	0.015	80	0.028	24	0.040	1.9	2.7
NBS-23	1.18	305	0.0095	79	0.025	12	0.033	2.6	3.5
NBS-24	1.19	305	0.0071	78	0.018	12	0.025	2.5	3.5
NBS-91	1.19	305	0.0066	81	0.023	23	0.032	3.5	4.8
NBS-101	1.09	305	0.11	81	0.26	47	0.33	2.4	3.0
Reference[14]		300	0.38	77	1.0			2.6	
Reference[19]		300	5.9	77	12.9	5	14.2	2.2	2.4

Table 5. Oxygen content of germanium crystals as determined by infrared absorption measurements on specimens at room temperature and at about 20 K

Crystal number	300 K - difference method			20 K - air reference method			20 K - difference method		
	α	Std. dev.	Oxygen	α	Std. dev.	Oxygen	α	Std. dev.	Oxygen
	cm ⁻¹		atoms/cm ³	cm ⁻¹		atoms/cm ³	cm ⁻¹		atoms/cm ³
NBS-01	0.015	0.002	19 × 10 ¹⁴	0.058	0.006	18 × 10 ¹⁴	0.040	.0004	12 × 10 ¹⁴
NBS-02							.0083	.0018	2.6
NBS-23	.0095	.0017					.033	.003	10
NBS-24	.0071	.0009	8.9	.036	.004	11	.025	.002	7.7
NBS-71							.0045	.0007	1.4
NBS-91	.0066	.0005	8.3	.033	.004	10	.032	.002	9.9
NBS-101	.113	.003	141	.35	.01	108	.33	.01	100
NBS-613							.0071	.0009	2.2

corrected for multiple internal reflections. The ratios for specimen NBS-91 are noticeably larger than those for the other specimens, but no explanation can be given.

Table 5 lists the absorption coefficient and oxygen content of germanium crystals as determined from infrared absorption measurements by the double-beam difference method at about 300 K and by the difference and air reference methods at about 20 K. All of the absorption coefficients have been corrected for multiple internal reflections. Each reported value is the average of 5 to 10 recordings of the absorption band and an estimated standard deviation of the mean was calculated from the individual measurements. There is probably additional systematic error as evidenced by disagreements between the results of the air reference and difference methods on the same specimen at the same temperature. A flat baseline occurs in the difference measurements and this reduces the error involved in sketching the steep baseline corresponding to an oxygen-free crystal, which is required to analyze the data with air in the reference beam. The oxygen concentrations at 300 K were obtained using the calibration of Millet, et al. For 20 K measurements the work of Fox was used to relate oxygen content to absorption coefficient.

A minimum absorption coefficient of about 0.003 cm^{-1} can be detected in a 1-cm thick specimen using the double-beam difference method with ordinate scale expansion. Of course, the accuracy is poor for coefficients this small. At 20 K, an absorption coefficient of 0.003 cm^{-1} corresponds to an oxygen concentration of just under 1×10^{14} atoms/cm³.

The oxygen content of most of the specimens listed in Table 5 has been determined by lithium precipitation and by lithium ion mobility. These results will be discussed and compared with the infrared absorption measurements in a forthcoming NBS Technical Note.

ACKNOWLEDGEMENTS

Some of the data presented were obtained on round robin specimens circulated by Subcommittee IV of ASTM Committee F-1 on Materials for Electron Devices and Microelectronics. The support of the Arms Control and Disarmament Agency and the AEC Division of Biology and Medicine for portions of the germanium work is gratefully acknowledged.

References

1. "Tentative Method of Test for Oxygen Content of Silicon," (ASTM Designation: F45-64T) *1969 Book of ASTM Standards*, Part 8; "Recommended Practices for Infrared Absorption Analysis of Impurities in Single Crystal Semiconductor Materials," "Method of Test for Interstitial Atomic Oxygen Content of Silicon by Infrared Absorption," and "Method of Test for Interstitial Atomic Oxygen Content of Germanium by Infrared Absorption" (ASTM Designations: F120-70T, F121-70T, and F122-70T respectively) to appear in *1970 Book of ASTM Standards*, Part 8.
2. H. N. Hersh, "Color Centers in X-rayed Potassium Iodide," *Phys. Rev.* 105, 1158-1167 (1957).
3. "Recommended Practices for General Techniques of Infrared Quantitative Analysis," (ASTM Designation: E168-67) *1969 Book of ASTM Standards*, Part 30.
4. W. Kaiser, P. H. Keck, and C. F. Lange, "Infrared Absorption and Oxygen Content in Silicon and Germanium," *Phys. Rev.* 101, 1264-1268 (1956).
5. B. Pajot, "Improvement in the Detection of Oxygen in Silicon by Infra-red Absorption," *Solid-State Electron.* 12, 923-925 (1969).
6. A. Smakula and J. Kalnajs, "Oxygen Impurity in Silicon Single Crystals," *J. Phys. Chem. Solids* 6, 46-50 (1958).
7. H. J. Hrostowski and R. H. Kaiser, "Infrared Absorption of Oxygen in Silicon," *Phys. Rev.* 107, 966-972 (1957).
8. J. A. Baker, to be published in *Solid State Electronics*.
9. W. Kaiser and P. H. Keck, "Oxygen Content of Silicon Single Crystals," *J. Appl. Phys.* 28, 882-887 (1957).
10. M. I. Iglitsyn, G. P. Kekelidze, and G. V. Lazareva, "Determination of the Amount of Oxygen in Silicon by the Lithium Diffusion Method," *Fiz. Tver. Tela* 6, 3148-3150 (1964) [Trans. *Soviet Physics - Solid State* 6, 2508-2509 (1965)].
11. G. I. Aleksandrova, A. M. Demidov, G. A. Kotel'nikov, G. P. Plashakova, G. V. Suknov, D. Ya. Choporov, and G. I. Shmanenkova, "Determination of Oxygen Content in Germanium and Silicon by Activation with He³ Ions," *Atomnaya Energiya* 23, 106-109 (1967) [Trans. *Soviet Atomic Energy* 23, 797-801 (1967)].
12. W. Kaiser and C. D. Thurmond, "Solubility of Oxygen in Germanium," *J. Appl. Phys.* 32, 115-118 (1961).

13. E. J. Millett, L. S. Wood, and G. Bew, "Oxygen in Germanium by Vacuum Fusion and Infra-red Absorption," *Brit. J. Appl. Phys.* 16, 1593-1594 (1965).
14. J. Bloem, C. Haas, and P. Penning, "Properties of Oxygen in Germanium," *J. Phys. Chem. Solids* 12, 22-27 (1959).
15. R. J. Fox, "Lithium Drift Rates and Oxygen Contamination in Germanium," *IEEE Trans. Nucl. Sci.* NS-13, 367-369 (1966).
16. W. Kaiser, R. J. Collins, and H. Y. Fan, "Infrared Absorption in P-Type Germanium," *Phys. Rev.* 91, 1380-1381 (1953).
17. H. B. Briggs and R. C. Fletcher, "Absorption of Infrared Light by Free Carriers in Germanium," *Phys. Rev.* 91, 1342-1346 (1953).
18. A. H. Kahn, "Theory of the Infrared Absorption of Carriers in Germanium and Silicon," *Phys. Rev.* 97, 1647-1652 (1955).
19. W. Kaiser, "Electrical and Optical Investigations of the Donor Formation in Oxygen-Doped Germanium," *J. Phys. Chem. Solids* 23, 255-260 (1962).

APPENDIX A

CALCULATION AND GRAPHS RELATING THE IMPURITY ABSORPTION COEFFICIENT OBTAINED BY THE APPROXIMATE EQUATION TO THAT FOUND FROM THE COMPLETE EQUATION FOR THE DIFFERENCE METHODS

The impurity absorption coefficient is determined by calculations involving the ratio of the transmittance at the impurity peak (T_m) to the transmittance at the same wavelength for no impurity absorption (T_o). The intensity in the sample beam of the spectrophotometer at the impurity peak is

$$I_s = \frac{KI_i(1-R)^2 e^{-\alpha_t x}}{1-R^2 e^{-2\alpha_t x}}$$

with the total absorption coefficient $\alpha = \alpha_i + \alpha_b$, where α_i is the impurity absorption coefficient and α_b is the background coefficient which includes lattice and free carrier absorption. The constant K represents an attenuation of the sample beam which is achieved by adjusting the 100 % control. The intensity in the reference beam which contains an impurity-free specimen is

$$I_r = \frac{I_i(1-R)^2 e^{-\alpha_b x}}{1-R^2 e^{-2\alpha_b x}}$$

The minimum transmittance at the impurity peak is

$$T_m = \frac{I_s}{I_r} = Ke^{-\alpha_i x} \frac{1-R^2 e^{-2\alpha_b x}}{1-R^2 e^{-2\alpha_t x}}$$

The baseline transmittance is $T_o = \frac{I_s}{I_r} \Big|_{\alpha_i=0} = K$.

Thus $\frac{T_m}{T_o} = e^{-\alpha_i x} \frac{1-R^2 e^{-2\alpha_b x}}{1-R^2 e^{-2\alpha_t x}}$.

When the approximate equation is used, an α'_i is obtained from $T_m/T_o = e^{-\alpha'_i x}$.

Equating the above two equations, the solution obtained for α'_i in terms of α_i and the other parameters is

$$\alpha'_i = \alpha_i + \frac{1}{x} \ln \left(\frac{1-R^2 e^{-2\alpha_t x}}{1-R^2 e^{-2\alpha_b x}} \right).$$

In the limit of small $\alpha_i x$ the above equation can be written as

$$\frac{\alpha'_i - \alpha_i}{\alpha_i} \Big|_{\alpha_i x \rightarrow 0} = \frac{2R^2 e^{-2\alpha_b x}}{1-R^2 e^{-2\alpha_b x}}$$

Thus the percent error is independent of α_i when α_i is small as clearly shown in the graphs which follow. In the limit of small $(\alpha_i + \alpha_b)x$, the quantity $(\alpha'_i - \alpha_i)/\alpha_i$ approaches $2R^2/(1-R^2)$, a limit dependent only on the reflectivity value. For semiconductors with a high reflectivity, such as germanium, this factor is large and corrections are needed when the approximate equation is used for calculations.




Figure 3. Graph for the difference methods of the percent difference between the impurity absorption coefficient determined using the complete transmittance equation and that found from the approximate equation for several values of specimen thickness x . The constants used were $R = 0.2995$ and $\alpha_b = 0.8 \text{ cm}^{-1}$, which are appropriate for the 9- μm oxygen band in silicon at 300 K.




Figure 4. Graph for the difference methods of the percent difference between the impurity absorption coefficient determined using the complete transmittance equation and that found from the approximate equation for several values of specimen thickness x . The constants used were $R = 0.360$ and $\alpha_b = 0.1 \text{ cm}^{-1}$, which are appropriate for the 11.7- μm oxygen band in germanium at 300 K.

CALCULATION AND GRAPH RELATING THE IMPURITY ABSORPTION COEFFICIENT OBTAINED BY THE APPROXIMATE EQUATION TO THAT FOUND FROM THE COMPLETE EQUATION FOR THE AIR REFERENCE METHOD

The impurity absorption coefficient is determined by calculations involving the ratio of the transmittance at the impurity peak (T_m) to the transmittance at the same wavelength for no specimen absorption (T_o). The intensity in the sample beam of the spectrophotometer at the impurity peak is

$$I_s = \frac{I_i (1-R)^2 e^{-\alpha_t x}}{1-R^2 e^{-2\alpha_t x}}$$

with $\alpha_t = \alpha_i + \alpha_b$, where α_i is the impurity absorption coefficient and α_b is the background coefficient which includes lattice and free carrier absorption. The intensity in the reference beam with only air is

$$I_r = K I_i$$

where the constant K represents an attenuator in the reference beam. The minimum transmittance at the impurity peak is

$$T_m = \frac{I_s}{I_r} = \frac{(1-R)^2 e^{-\alpha_t x}}{K (1-R^2 e^{-2\alpha_t x})}$$

Assume that the baseline is drawn to coincide with the transmittance for no specimen absorption (only reflectivity losses); then

$$T_o = \left. \frac{I_s}{I_r} \right|_{\alpha_t = 0} = \frac{(1-R)^2}{K (1-R^2)}$$

Thus

$$\frac{T_m}{T_o} = e^{-\alpha_t x} \frac{(1-R^2)}{1-R^2 e^{-2\alpha_t x}}$$

When the approximate equation is used, an α'_t is obtained from $T_m/T_o = e^{-\alpha'_t x}$.

Equating the above two equations, the solution obtained for α'_t in terms of α_t and the other parameters is

$$\alpha'_t = \alpha_t + \frac{1}{x} \ln \left(\frac{1-R^2 e^{-2\alpha_t x}}{1-R^2} \right)$$

Using the relations that $\alpha'_t = \alpha'_i + \alpha_b$ and $\alpha_t = \alpha_i + \alpha_b$, it is possible to write the above equation as

$$\frac{\alpha'_i - \alpha_i}{\alpha_i x} = \frac{1}{\alpha_i x} \ln \left(\frac{1-R^2 e^{-2(\alpha_i + \alpha_b)x}}{1-R^2} \right)$$

It is clear from this equation and the graph on the next page that the approximate equation should not be used unless the impurity absorption is larger than any competing background absorption regardless of the value of the reflectivity. Providing there is no competing absorption ($\alpha_b = 0$), the approximate equation can be used with the air reference method when $\alpha_i x$ is small, as the correction factor is simply $2R^2/(1-R^2)$, which is the limit found in the same situation for the difference methods. It is well to remember that this factor is significant when R is large. For silicon with $R = 0.30$, it is a 20 percent correction. In the limit of large $\alpha_i x$ no correction is needed of course.





Figure 5. Graph for the air reference method of the percent difference between the impurity absorption coefficient determined using the complete transmittance equation and that found from the approximate equation for several values of specimen thickness x . The constants used were $R = 0.2995$ and $\alpha_D = 0.8 \text{ cm}^{-1}$, which are appropriate for the $9\text{-}\mu\text{m}$ oxygen band in silicon at 300 K.



THE NATIONAL ECONOMIC GOAL

Sustained maximum growth in a free market economy, without inflation, under conditions of full employment and equal opportunity

THE DEPARTMENT OF COMMERCE

The historic mission of the Department is "to foster, promote and develop the foreign and domestic commerce" of the United States. This has evolved, as a result of legislative and administrative additions, to encompass broadly the responsibility to foster, serve and promote the nation's economic development and technological advancement. The Department seeks to fulfill this mission through these activities:



MISSION AND FUNCTIONS OF THE DEPARTMENT OF COMMERCE

"to foster, serve and promote the nation's economic development and technological advancement"

Participating with other government agencies in the creation of national policy, through the President's Cabinet and its subdivisions.

- Cabinet Committee on Economic Policy
- Urban Affairs Council
- Environmental Quality Council

Promoting progressive business policies and growth.

- Business and Defense Services Administration
- Office of Field Services

Assisting states, communities and individuals toward economic progress.

- Economic Development Administration
- Regional Planning Commissions
- Office of Minority Business Enterprise

Strengthening the international economic position of the United States.

- Bureau of International Commerce
- Office of Foreign Commercial Services
- Office of Foreign Direct Investments
- United States Travel Service
- Maritime Administration

Assuring effective use and growth of the nation's scientific and technical resources.

- Environmental Science Services Administration
- Patent Office
- National Bureau of Standards
- Office of Telecommunications

Acquiring, analyzing and disseminating information concerning the nation's economy to achieve increased social and economic benefit.

- Bureau of the Census
- Office of Business Economics

NOTE: This schematic is neither an organization chart nor a program outline for budget purposes. It is a general statement of the Department's mission in relation to the national goal of economic development.

NBS TECHNICAL PUBLICATIONS

PERIODICALS

JOURNAL OF RESEARCH reports National Bureau of Standards research and development in physics, mathematics, chemistry, and engineering. Comprehensive scientific papers give complete details of the work, including laboratory data, experimental procedures, and theoretical and mathematical analyses. Illustrated with photographs, drawings, and charts.

Published in three sections, available separately:

● Physics and Chemistry

Papers of interest primarily to scientists working in these fields. This section covers a broad range of physical and chemical research, with major emphasis on standards of physical measurement, fundamental constants, and properties of matter. Issued six times a year. Annual subscription: Domestic, \$9.50; foreign, \$11.75*.

● Mathematical Sciences

Studies and compilations designed mainly for the mathematician and theoretical physicist. Topics in mathematical statistics, theory of experiment design, numerical analysis, theoretical physics and chemistry, logical design and programming of computers and computer systems. Short numerical tables. Issued quarterly. Annual subscription: Domestic, \$5.00; foreign, \$6.25*.

● Engineering and Instrumentation

Reporting results of interest chiefly to the engineer and the applied scientist. This section includes many of the new developments in instrumentation resulting from the Bureau's work in physical measurement, data processing, and development of test methods. It will also cover some of the work in acoustics, applied mechanics, building research, and cryogenic engineering. Issued quarterly. Annual subscription: Domestic, \$5.00; foreign, \$6.25*.

TECHNICAL NEWS BULLETIN

The best single source of information concerning the Bureau's research, developmental, cooperative and publication activities, this monthly publication is designed for the industry-oriented individual whose daily work involves intimate contact with science and technology—for *engineers, chemists, physicists, research managers, product-development managers, and company executives*. Annual subscription: Domestic, \$3.00; foreign, \$4.00*.

* Difference in price is due to extra cost of foreign mailing.

Order NBS publications from:

Superintendent of Documents
Government Printing Office
Washington, D.C. 20402

NONPERIODICALS

Applied Mathematics Series. Mathematical tables, manuals, and studies.

Building Science Series. Research results, test methods, and performance criteria of building materials, components, systems, and structures.

Handbooks. Recommended codes of engineering and industrial practice (including safety codes) developed in cooperation with interested industries, professional organizations, and regulatory bodies.

Special Publications. Proceedings of NBS conferences, bibliographies, annual reports, wall charts, pamphlets, etc.

Monographs. Major contributions to the technical literature on various subjects related to the Bureau's scientific and technical activities.

National Standard Reference Data Series. NSRDS provides quantitative data on the physical and chemical properties of materials, compiled from the world's literature and critically evaluated.

Product Standards. Provide requirements for sizes, types, quality and methods for testing various industrial products. These standards are developed cooperatively with interested Government and industry groups and provide the basis for common understanding of product characteristics for both buyers and sellers. Their use is voluntary.

Technical Notes. This series consists of communications and reports covering both other agency and NBS-sponsored work of limited or transitory interest.

Federal Information Processing Standards Publications. This series is the official publication within the Federal Government for information on standards adopted and promulgated under the Public Law 89-306, and Bureau of the Budget Circular A-86 entitled, Standardization of Data Elements and Codes in Data Systems.

CLEARINGHOUSE

The Clearinghouse for Federal Scientific and Technical Information, operated by NBS, supplies unclassified information related to Government-generated science and technology in defense, space, atomic energy, and other national programs. For further information on Clearinghouse services, write:

Clearinghouse
U.S. Department of Commerce
Springfield, Virginia 22151

U.S. DEPARTMENT OF COMMERCE
WASHINGTON, D.C. 20230

OFFICIAL BUSINESS



POSTAGE AND FEES PAID
U.S. DEPARTMENT OF COMMERCE
